

EPJ-6 Series Junction Box

Installation & Maintenance Information



SAVE THESE INSTRUCTIONS FOR FUTURE REFERENCE

APPLICATION

EPJ-6 Series Junction Boxes are used in threaded rigid conduit systems in hazardous areas to function as a junction or pull box where space is limited.

EPJ-6 junction boxes are suitable for use in Class I, Groups C and D; Class II, Groups E, F, G; and Class III hazardous (classified) areas as defined by the National Electrical Code® and the Canadian Electrical Code®.

INSTALLATION

WARNING

Electrical power **must be OFF** before and during installation and maintenance.

CAUTION

- Hazardous location information specifying class and group listing is marked on the cover of each junction box.
- All unused conduit opening must be plugged. Plug must engage a minimum of five (5) full threads and be a minimum of 1/8" thick.

1. Securely fasten enclosure into conduit system and make certain that conduit is wrench tight.
2. Unthread enclosure cover and carefully set it aside to prevent damage to the cover threads.

CAUTION

Use care to prevent dirt, grit, or other foreign material from lodging onto threads. If any such material settles on these threads, clean them with kerosene or Stoddard solvent, then relubricate with thread lubricant. To prevent oxidation and corrosion or the possibilities of an explosion hazard, do not use gasoline or similar solvents.

3. Pull wires into enclosure, making sure they are long enough to make the required electrical connections. Make all electrical connections.
4. Test wiring for correctness with continuity checks and also for unwanted grounds with insulation resistance tester.
5. Re-thread cover into enclosure housing and tighten cover.



MAINTENANCE

WARNING

Always disconnect primary power source before opening enclosure for inspection or service.

1. Frequent inspection should be made. A schedule for maintenance check should be determined by the environment and frequency of use. It is recommended that it should be at least once a year.
2. Perform visual, electrical, and mechanical checks on all components on a regular basis.
 - Visually check for undue heating evidenced by discoloration of wires or other components, damaged parts, or leakage evidenced by water or corrosion in the interior.
 - Electrically check to make sure that all connections are clean and tight.
 - Mechanically check that all parts are properly wired.

All statements, technical information and recommendations contained herein are based on information and tests we believe to be reliable. The accuracy or completeness thereof are not guaranteed. In accordance with Larson Electronics "Terms and Conditions of Sale," and since conditions of use are outside our control, the purchaser should determine the suitability of the product for his intended use and assumes all risk and liability whatsoever in connection therewith.

E X P E D I T E D S H I P P I N G · S U P E R I O R C U S T O M F A B R I C A T I O N

LARSON ELECTRONICS LLC • 9419 E US HWY 175 • KEMP, TX 75143
p: 1-800-369-6671 • Int'l: 903-498-3363 • f: 903-498-3364 • sales@larsonelectronics.com