100' 12/4 SOOW Twist Lock Extension Power Cord
Instruction Manual

Do not attempt operation until you are familiar with all warnings, precautions, and procedures outlined within this instruction sheet. Read carefully before operating. Retain these instructions for future reference.

WARNING:

USER SHOULD BE TRAINED IN THE PROPER USE AND MAINTENANCE OF THIS DEVICE. THIS LINE CORD IS INTENDED TO ALLOW OPERATORS TO EXTEND POWER TO EQUIPMENT WHEN STATIONARY OUTLETS ARE NOT READILY AVAILABLE.

IMPROPER USE OF THIS CORD, PLUG, AND RECEPTACLE CAN LEAD TO SERIOUS INJURIES OR DEATH TO PERSONNEL.

PERIODIC INSPECTION OF THE CORD IS NECESSARY.
THE CORD MUST BE ROUTINELY CHECKED FOR CUTS, BREAKS, OR ANY SEVERE ABRASIONS, AND IF ANY ARE FOUND, THE CORD MUST BE REPLACED BEFORE RESUMING USE OF THE HANDLAMP.

OPERATION

Insert L15-30P male end into matching receptacle outputting no more than max specifications shown below. Plug compatible equipment into L15-30C connector on other end.

Specifications

Male Cord Cap: L15-30P
Female Cord Cap: L15-30C
Voltage Rating: 250V
Max Amp Rating: 20A
Cable Type: 12/4 SOOW
Cable Length: 100'



USE AND CARE

Unauthorized modification may impair the function and/or safety of the extension cord and could affect the life of the equipment. Always check damaged or worn out parts before using. When not in use, store in a secure place out of the reach of children. Inspect for good working condition prior to storage and before re-use.

REPLACEMENT PARTS

The EXC-100-12.4-20A-L15.30 is designed to provide years of reliable performance. Should the need for replacement parts arise, please contact Larson Electronics.

Should further information not covered by these instructions be required, please contact Larson Electronics at 1-800-369-6671 or sales@larsonelectronics.com for further assistance.

Please visit LarsonElectronics.com for **Warranty** and **Return** information.