Portable Rechargeable LED Tripod Light
Instruction Manual

Do not attempt operation until you are familiar with all warnings, precautions, and procedures outlined within this instruction sheet. Read carefully before operating. Retain these instructions for future reference.

WARNING:

- DO NOT CHARGE NEAR WATER OR WHERE WATER MAY ACCUMULATE.
- KEEP PLUGS AND RECEPTACLES DRY.
- KEEP LIGHTED LAMP AWAY FROM COMBUSTIBLES.
- DO NOT TOUCH HOT LENS GUARD OR ENCLOSURE.
- DO NOT REMAIN IN LIGHT IF SKIN FEELS WARM.
- DO NOT LOOK DIRECTLY AT LIGHTED LAMP.
- KEEP LAMP AWAY FROM MATERIALS THAT MAY BURN.

Wall Charger operates on **120V AC only**.
Vehicle Charger operates on **12V DC only**.



USING THE TRIPOD

1. To assemble the tripod, begin by loosening the black adjustment knob on the tripod base. Slide the center pole through the adjustment sleeve until the legs are fully deployed. Tighten adjustment knob so legs stay fixed in place. Now you are ready to install top portion.
2. Position LED lamp over the top hole on tripod and screw down until snug.
3. Loosen the black adjustment knob for each adjustment sleeve to extend the tripod.
4. Tighten adjustment knob once desired height is achieved.
5. Attach power cord to battery or 12V DC vehicle socket.

OPERATION

Locate the inline power switch and use it to power the light **ON** or **OFF**. This lighting system provides a 4 hour runtime on a single charge.

CHARGING

Fully charge the battery before first use. To charge the battery, disconnect the LED light and insert the charger cable.



Vehicle Charger: Insert the male cigarette plug with the gold plated end into the battery's female charging socket and the larger cigarette plug into your vehicle's cigarette lighter power supply providing **12V DC**.



Wall Charger: Insert the male cigarette plug with the gold plated end into the battery's female charging socket. Plug the other end into a standard wall plug providing **120V AC**.

The red LED on the charger housing must light to insure that the battery is being charged. Keep the battery and charger contacts clean at all times. Poor contact can cause charger malfunctions. An abrasive pencil eraser works well to clean the contacts.



USE AND CARE

Do not modify the work light in any way. Unauthorized modification may impair the function and/or safety and could affect the life of the equipment. There are specific applications for which the work light was designed. Always check damaged or worn out parts before using the work light. Broken parts will affect the work light operation. When work light is not in use, store it in a secure place out of the reach of children. Inspect it for good working condition prior to storage and before re-use.

MAINTENANCE

Maintain your work light. It is recommended that the general condition of any work light be examined before it is used. Keep your work light in good repair by adopting a program of conscientious repair and maintenance. Have necessary repairs made by qualified service personnel.

Should further information not covered by these instructions be required, please contact Larson Electronics at 1-800-369-6671 or sales@larsonelectronics.com for further assistance.

Please visit LarsonElectronics.com for **Warranty** and **Return** information.