R-x Series

Replacement Lamp for ML, HML, CML, MUL Series Spotlights Instruction Manual

CAUTION: **Disconnect power and allow lamp to cool prior to performing maintenance!**

BULB REPLACEMENT

To replace the bulb:

1. Remove the screw on the bottom of the face ring.
2. Carefully take the face ring off and pull the bulb out of the socket freeing it from the spring fasteners.
3. Place the new bulb in its socket and replace face ring.



THESE INSTRUCTIONS MAY NOT COVER ALL DETAILS OR VARIATIONS OF THIS PRODUCT FOR YOUR EQUIPMENT OR INSTALLATION REQUIREMENTS. SHOULD FURTHER INFORMATION NOT COVERED BY THESE INSTRUCTIONS BE REQUIRED, PLEASE CONTACT LARSON ELECTRONICS BY EMAIL AT SALES@LARSONELECTRONICS.COM OR BY PHONE AT 1-800-369-6671 FOR FURTHER ASSISTANCE.

PLEASE VISIT LARSONELECTRONICS.COM FOR **WARRANTY** AND **RETURN** INFORMATION.