Replacement Lens Clip for GVP Series Linear Fixtures
Price Per Unit
Instruction Manual

Thank you for your purchase of the Larson Electronics GVP-4824-XX-SP0109.

WARNING:

READ CAREFULLY BEFORE INSTALLING FIXTURE. RETAIN THESE INSTRUCTIONS FOR FUTURE REFERENCE.
CRITICAL SAFETY INSTRUCTIONS:

- INSTALLATION SHOULD ONLY BE CONDUCTED BY A QUALIFIED ELECTRICIAN IN ACCORDANCE WITH NEC AND ANY RELEVANT LOCAL BUILDING CODES.
- RISK OF FIRE OR ELECTRIC SHOCK. FIXTURE INSTALLATION REQUIRES KNOWLEDGE OF FIXTURE'S ELECTRICAL SYSTEMS. IF NOT QUALIFIED, CONTACT A QUALIFIED ELECTRICIAN.
- BE CERTAIN ELECTRICAL POWER IS OFF BEFORE AND DURING INSTALLATION AND MAINTENANCE.
- MAKE SURE THE SUPPLY VOLTAGE IS THE SAME AS THE FIXTURE'S RATED VOLTAGE.
- TO PREVENT WIRING DAMAGE OR ABRASION, DO NOT EXPOSE WIRING TO EDGES OF SHEET METAL OR SHARP OBJECTS. SUITABLE FOR DAMP LOCATIONS.

Never place spotlight face down when light is on. Doing so could burn/ignite surfaces such as seats, carpeting, etc. and cause major property damage. Always turn spotlight off when not in use.

Avoid direct eye exposure the light source when light is on. **DO NOT** shine light into the face of someone else.
DO NOT touch lens of light when on or recently on. The lens/cooling fins will be hot after long periods.
DO NOT allow children to handle or operate this light.
DO NOT use this product for other than its intended use.
DO NOT operate in close proximity of combustible or flammable materials.
DO NOT attempt to operate this light if cord, plug, battery, lens or any part of the light is damaged or corroded.

Replacement Lens Clip for GVP Series Linear Fixtures. Sold individually. Each GVP-48 fixture requires (10) clips. Each GVP-24 fixture requires (6) clips. Compatible with GVP-48-1L, GVP-48-2L, GVP-48-3L, GVP-24-1L, GVP-24-2L, GVP-24-3L, and the GVP-EMG equivalents.

INSTALLATION

- Disconnect current unit from all power and ensure unit is cool to the touch.
- Remove current lens clips carefully making sure not to drop the lens.
- Replace the old lens clips with desired new replacement lens clips and carefully assemble product.
- Reconnect fixture to power before continuing use.

MAINTENANCE

There are no serviceable parts inside the fixture. However, it is good practice to routinely clean and check the fixture for proper function.

USE AND CARE

Unauthorized modification may impair the function and/or safety of this device and could affect the life of the equipment. Always check for damaged or worn out parts before using the device. Store it in a secure place out of the reach of children when not in use. Inspect for good working condition prior to storage and before re-use.

REPLACEMENT PARTS

The GVP-4824-XX-SP0109 is designed to provide years of reliable performance. Should the need for replacement parts arise, please contact Larson Electronics.

THESE INSTRUCTIONS MAY NOT COVER ALL DETAILS OR VARIATIONS OF THIS PRODUCT FOR YOUR EQUIPMENT OR INSTALLATION REQUIREMENTS. SHOULD FURTHER INFORMATION NOT COVERED BY THESE INSTRUCTIONS BE REQUIRED, PLEASE CONTACT LARSON ELECTRONICS BY EMAIL AT SALES@LARSONELECTRONICS.COM OR BY PHONE AT 1-800-369-6671 FOR FURTHER ASSISTANCE.

PLEASE VISIT LARSONELECTRONICS.COM FOR **WARRANTY** AND **RETURN** INFORMATION.