Larson Electronics LLC www.LarsonElectronics.com sales@larsonelectronics.com
9419 E US HWY 175, Kemp, TX 75143 - P: (800) 369-6671 - F: (903) 498-3364

990X-M-DC

NOTICE:

- Do not operate the 990X-M-DC in an environment where flammable gases may be present.
- Do not stare directly into the light or shine directly into the eyes of another person as this may cause temporary loss of vision.
- Do not let water enter the case, while the 990X-M-DC is both weather and water resistant, it is not designed to be submersible.
- If the 990X-M-DC is damaged, do not turn on until it has been inspected by an authorized service center.
- Never touch any exposed sections, especially any wires, as this may cause serious injury from high voltage electrical shock.
- Do not operate the flashlight if the front lens is cracked or removed.
- Never disassemble the 990X-M-DC, as all parts must be factory serviced to insure proper operation.
- Do not store the light and battery in locations where the temperature may exceed 104 degrees F (40 degrees C) or wet/damp locations of high humidity.
- Should the operating time show significant decrease (even after full charging), battery replacement will be required.
- If the 990X-M-DC is to be stored for long periods of time, remove the battery from the flashlight.
- Do not allow objects or skin to contact the lens after extended operation.
- Do not operate the 990X-M-DC during charging stage.
- Due to high intensity discharge characteristics and to prolong bulb life, do not continuously switch the light on and off, and wait 5 minutes before restarting.

FEATURES:

- Swivel light head with multiple angle adjustments for different operational requirements.
- Adjustable flood to spot beam pattern using lens focus ring.
- Built in LED indicator inside the battery and with a full charge the battery will last as long as 70 minutes.

OPERATING:

1. **INSTALLING THE BATTERY:** Insert the battery in the manner shown on figure A-1. Be sure the battery is fully locked into position.
2. **TO REMOVE THE BATTERY:** Grasp the battery firmly and press the battery release button (located on side) and pull straight out.
3. **TURNING ON:** Slide the on/off switch towards the front lens to turn on and backwards, towards the battery, to turn off.

Larson Electronics LLC **www.LarsonElectronics.com** **sales@larsonelectronics.com**
9419 E US HWY 175, Kemp, TX 75143 - P: (800) 369-6671 - F: (903) 498-3364

MAINTENANCE:

- Periodically clean the surface with a cloth (moistened with a mild detergent)
- Clean the front lens after it has cooled with glass cleaner. Use of harsh cleaners may cause discoloration of the surface.
- The 990X-M-DC has been designed for maintenance free use. In the event a bulb or other part replacement becomes necessary, please contact Magnalight. Other than battery replacement there are no user serviceable parts.