Larson Electronics LLC www.LarsonElectronics.com sales@larsonelectronics.com
9419 E US HWY 175, Kemp, TX 75143 - P: (800) 369-6671 - F: (903) 498-3364

RL-11-IRF

IR FILTER

1. Place the filter assembly over the face of the lamp.
2. For RL-11 model lamps, use the U-bolt provided by looping it through the open area just below the handle and to the rear of the lamp head. Feed the ends through the two ears of the filter head.
   NOTE: This may require light pressure when sliding the bolt ends through the ears of the head assembly. This bolt will only fit one way; do not force the bolt as this may damage the lamp and/or the filter.
3. Install and tighten, by hand only, the thumbnuts until the seal is compressed to eliminate light leakage during operation.

Please Note: This filter will become hot during use and should not be touched with bare hands. Allow adequate time to cool before removal. Never stare directly into the lamp regardless of filter used. This may cause temporary loss of vision.