DCP-20

OPERATION

1. Insert AC power plug into a 110/120 volt AC outlet.
2. Connect the power cord of your equipment with proper input voltage to the output binding post terminals on front of the unit. Be sure that polarity is correct. The red positive (+) terminal and black negative (-) terminal are marked. Reversal of polarity may damage your equipment.
3. Turn switch to “ON”. The light in the switch will illuminate.
4. The input power is protected by the fuse which is located at the rear of the unit and can be replaced by unscrewing the fuse holder if the fuse is burnt out. Please use the same rated fuse for replacement.
5. This unit has short-circuit protection with an automatic reset function.

CAUTION

- Do not use with equipment requiring more than rated amps.
- Do not use outdoors. Do not expose unit to rain, moisture, water, or any other liquids.
- Do not remove cover. Return to dealer for repair if damaged.
- This unit is an economic type. Do not use it on full load for long periods of time.

LARSON ELECTRONICS LLC • 9419 E US HWY 175 • KEMP, TX 75143
p: 1-800-369-6671 • intl: 903-498-3363 • f: 903-498-3364 • sales@larsonelectronics.com