Larson Electronics LLC **www.LarsonElectronics.com** **sales@larsonelectronics.com**
9419 E US HWY 175, Kemp, TX 75143 - P: (800) 369-6671 - F: (903) 498-3364

HUL-18-HID

NOTICE

- Do not operate the HUL-18-HID in an environment where flammable gases may be present.
- Do not stare directly into the light or shine directly into the eyes of another person as this may cause temporary loss of vision.
- If damage occurs, do not operate until it has been inspected by an authorized service center.
- Never touch any exposed sections, especially any wires, as this may cause serious injury from high voltage electrical shock.
- Do not operate the flashlight if the front lens is cracked or removed.
- Do not allow objects or skin to contact the lens after extended operation.
- Due to high intensity discharge characteristics and to prolong bulb life, do not continuously switch the light on and off.

POWER

1. The HUL-18 is equipped with a 16 foot coil cord with a cigarette plug.
2. Each unit is configured for either 12 volts or 24 volts DC. The 12 volt models can be plugged into 12 volt DC power supplies, which most consumer vehicles operate on. The 24 volt models can be plugged into a 24 volt DC power supply, generally for military and heavy equipment.
   PLEASE NOTE: There is no difference in light output between a 12 volt and 24 volt model. Each unit is configured to a specific voltage and IS NOT interchangeable.
3. Power transformers (DCP-11-DP) can be purchased through our website to run this halogen spotlight from household wall outlets.

REPLACING THE BULB

Replacement bulbs are available on our website at www.Larsonelectronics.com.
(Part Number HUL-18-HID-SB)

1. Four (4) screws hold the housing and the lens together. To replace the bulb you must use a Philips head screw driver to remove the screws.
2. Unplug both of the deutsch connectors from the used bulb.
3. Remove both of the wire prongs that hold the bulb in place. You should now be able to remove the bulb.

4. Insert the new bulb by plugging the deutsch connectors back in.
5. Be sure to connect the two wire prongs on the new bulb.
6. Align the screw holes on the cover with those of the holes in the housing and insert the screws back in to place.

DETACHABLE CORDS

- Each cord is attached via a weatherproof 2-pin Deutsch connector.
- The cords are detachable by depressing the tab on the top of the connectors.
- Additional or replacement cords can be ordered from our website.

* We offer 16 foot coil cords with a cigarette plug (C-16-CC-CP), 21 foot cords with ring terminals (C-21-RT), 16 foot cords with battery clamps (C-16-BC), and 16 foot straight cords with cigarette plugs (C-16-CP).