Larson Electronics LLC www.LarsonElectronics.com sales@larsonelectronics.com
9419 E US HWY 175, Kemp, TX 75143 - P: (800) 369-6671 - F: (903) 498-3364

HID-RL11-SB

Bulb Changing Instructions:

1. Remove the end cap, opposite of the lens, by twisting, to expose the battery.
2. Remove the battery.
3. Remove the lens cover by twisting. There are 2 parts to the lens cover; the lens itself and the beauty ring (1 inch wide ring that goes around the lens).
   Note: This may require 2 people; one to hold the lens cover and the other person to twist the whole unit.
4. Once the lens cover is removed, pull out the lens to expose the bulb.
5. The bulb is held in with 2 small screws, and 2 wires.
6. Disconnect the 2 wires.
7. Unscrew the 2 small screws holding the bulb in place.
8. Pull the bulb out of the socket.
9. Replace with the new bulb.
10. Reconnect the 2 wires.
11. Insert the 2 small screws that hold the bulb in place.
12. Screw the lens cover back on until the beauty ring is tight and doesn't spin.
13. Insert battery.
14. Screw on the end cap.
15. Your light is now ready to operate

If you have any questions, please call the manufacturer at 1-800-369-6671.