Explosion Proof LED Traffic Wand
Instruction Manual

Do not attempt operation until you are familiar with all warnings, precautions, and procedures outlined within this instruction sheet. Read carefully before operating. Retain these instructions for future reference.

WARNING:

- Read all instructions before operating
- Do not look directly at the light; may cause injury to your eyes
- Never use if wiring or circuits are exposed or damaged
- Do not use alcohol, flammable solutions, or other solvents on this unit. Only clean with warm water and a soft cloth.
- Administer close supervision when using around children
- To reduce the risk of ignition of a flammable or explosive atmosphere, batteries must be changed only in a location known to be non-hazardous.
- To reduce the risk of explosion, do not mix old batteries with used batteries or mix batteries from different manufactures.
- Replace batteries only with the following models: Duracell, AA, Alkaline model MN1500 Energizer, AA, Alkaline model E91

Weatherproof and intrinsically safe, this traffic wand is Class 1 & 2, Division 1 & 2 rated and is ideal for directing traffic and signaling within hazardous locations.





USING THE TRAFFIC WAND

The traffic cone snaps onto the flashlight for high visibility. Place the cone onto the flashlight and press the rubber push button power switch to illuminate the wand. Press the power switch again to turn the off the light.

To turn this explosion proof traffic wand into a high output explosion proof flashlight, simply remove the cone. This allows operators to illuminate their surroundings as necessary. Replace the cone when required.

REPLACING THE BATTERIES

1. Ensure battery replacement is taking place in a non-hazardous location.
2. Unscrew bottom cap to remove batteries. Place new, approved batteries in the flashlight.





USE AND CARE

Unauthorized modification may impair the function and/or safety of the traffic wand and could affect the life of the equipment. Always check damaged or worn out parts before using the traffic wand. When w not in use, store it in a secure place out of the reach of children. Inspect for good working condition prior to storage and before re-use.

REPLACEMENT PARTS

The EXP-TW-LED-F4W is designed to provide years of reliable lighting performance. Should the need for replacement parts arise, please contact Larson Electronics at the contact information below.

Should further information not covered by these instructions be required, please contact Larson Electronics at 1-800-369-6671 or sales@larsonelectronics.com for further assistance.

Please visit LarsonElectronics.com for **Warranty** and **Return** information.