Replacement Stainless Steel Latch for HAL-48-2L-LED-BMSW
Instruction Manual

Do not attempt installation until you are familiar with all warnings and procedures outlined within this instruction sheet.

WARNING:

READ CAREFULLY BEFORE INSTALLING FIXTURE. RETAIN THESE INSTRUCTIONS FOR FUTURE REFERENCE.
CRITICAL SAFETY INSTRUCTIONS:

- BE CERTAIN ELECTRICAL POWER IS OFF BEFORE AND DURING MAINTENANCE.

INSTALLATION

We strongly recommend only a licensed electrician install and maintain this product. Make sure power is disconnected prior to installing. Fixture must be mounted to a surface that can structurally support the load.



Mount following the steps below:

1. Remove front lens, lights, and light panel.
2. Remove rivets holding latch to be replaced and remove latch.
3. Place new latch and secure to light fixture.
4. Replace light panel, lights, and lens.
5. Check new latch for proper function.

USE AND CARE

Always check damaged or worn out parts before using the light fixture. Broken parts will affect operation.

Should further information not covered by these instructions be required, please contact Larson Electronics at 1-800-369-6671 or sales@larsonelectronics.com for further assistance.

Please visit LarsonElectronics.com for **Warranty** and **Return** information.