LIGHT MAST OPERATION

LM Multi Stage Series

Read instructions carefully before attempting to install or operate the mast. Failure to comply with instructions and guidelines could result in serious or fatal injury, as well as void any warranty. Retain these instructions for future reference.

EXTEND MAST



1. Position light mast in the desired location. Ensure that the unit is **completely level** and anchor the light mast using all four (4) mounting holes located on the base. This will require four (4) 3/4" bolts. When picking a location, ensure the mast is free and clear from any overhead obstructions.




2. (If applicable) Attach equipment to mast head. Use appropriate measures for securing attached devices. Drill thru-holes as necessary. ***Do not exceed weight capacity listed on nameplate!***
3. Install mast head. *See mast head installation steps.*

NON-FOLD OVER MODELS

MAST HEAD INSTALLATION:
See Light Head Installation Section.

Pg. 2



4. Use the hand winch for extending the mast. Turn this clockwise until it stops. You should hear a clicking noise from the hand winch indicating the proper direction. **Do not force the winch any further passed its stopping point!**

LOWER MAST



1. To lower the mast, rotate the upper winch counter-clockwise. The winch will not click at this point and you should visually see the mast lowering. Stop once there is no more tension on the cable. *Do not allow excessive slack on winch cable.*

WARNING: *Power cables can become pinched or tangled around light mast while lowering or rotating. Take caution in keeping cables clear.*

ROTATING MAST (If applicable)

The mast can be rotated while lowered or elevated.



1. Loosen bolt(s) located toward center collar of light mast.
2. Rotate mast to desired angle.
3. Tighten bolt(s) in order to secure mast in place.

When using power cables, minimize full 360° rotation to prevent tangling cord around light mast. *Ensure cables are not in the way or tangled when lowering mast!*


Powering Devices

The LML-7-CU12-NYC-MOD1 telescoping mast comes with a CAT5e and 12/4 SOOW cord inside a nycoil coiled cable. The coiled cable is externally mounted for accessibility, and makes connecting power to devices on the mast head quick and easy.

MAST HEAD INSTALLATION


The light mast ships with the light head / T-head removed to prevent damage during transport. Follow the steps below for installing or removing light head.

1. Locate light head. Color, style, and mounted lights will vary.



COLOR MAY VARY

2. The light head is equipped with a T-Handle / Hand Screw.



3. Make sure the hand screw is loose, to allow the head to slide over the top stage of the mast.

4. Using a pair of slings, wrap both slings around the light head in between the lights on both sides.




5. Attach the slings to a forklift or other lifting device.



6. With 2 people holding the light head steady, slowly raise the light head above the mast.




7. A ladder will need to be placed on both sides of the mast, in order for 2 people to guide the head in to place.



8. Once the light head is on top of the light mast, tighten the T-Handle to ensure the light head is safely secured to the top of the mast.

9. Make the electrical connections for the lights. Repeat this process in reverse order for removing the light head.



10. Proceed to the **OPERATION MANUAL** for operating the unit.

Slings are recommended for installing heavy loads and to ensure operator safety. Should other methods be used, Larson Electronics shall not be held responsible for damages or personal injuries.

LARSON ELECTRONICS

9419 US-HWY 175
Kemp, TX 75143 USA
P: 800-369-6671 | INTL: 903-498-3363 F: 903-498-3364
sales@larsonelectronics.com
www.larsonelectronics.com