Portable Telescoping LED Light Tower
Instruction Manual

Do not attempt operation until you are familiar with all warnings, precautions, and procedures outlined within this instruction sheet. Read carefully before operating. Retain these instructions for future reference.

WARNING:

- KEEP LIGHTED LAMP AWAY FROM COMBUSTIBLES.
- DO NOT TOUCH HOT LENS GUARD OR ENCLOSURE.
- DO NOT REMAIN IN LIGHT IF SKIN FEELS WARM.
- DO NOT LOOK DIRECTLY AT LIGHTED LAMP.
- KEEP LAMP AWAY FROM MATERIALS THAT MAY BURN.

USING THE TRIPOD

1. To assemble the tripod, begin by loosening the black adjustment knob on the tripod base. Slide the center pole through the adjustment sleeve until the legs are fully deployed. Tighten adjustment knob so legs stay fixed in place. Now you are ready to install top portion.
2. Position light head over top pole on tripod and tighten black adjustment knob until snug.
3. Attach Deutsch connectors between the lights and switch box to provide power to lights.
4. Loosen black adjustment knob for each sleeve to extend tripod. Extend top pole, then bottom pole when elevating.
5. Tighten adjustment knob once desired height is achieved.
6. Attach power cord to compatible outlet with voltage listed on nameplate. **Voltage: 120-277V AC 50/60Hz.**



OPERATION

The light head features 2, 72 watt LED work lights. There are toggle switches on the back of the unit, one for each light. Do not look directly into lights when powering.

Each lamp can be adjusted independently with the adjustment screws on the sides. Tighten screw once desired angle is achieved.



USE AND CARE

Always check damaged or worn out parts before using the work light. When work light is not in use, store it in a secure place out of the reach of children. Inspect for good working condition prior to storage and before re-use.

Should further information not covered by these instructions be required, please contact Larson Electronics at 1-800-369-6671 or sales@larsonelectronics.com for further assistance.

Please visit LarsonElectronics.com for **Warranty** and **Return** information.



QUICK DISCONNECT
DEUTSCH CONNECTOR

THESE INSTRUCTIONS MAY NOT COVER ALL DETAILS OR VARIATIONS OF THIS PRODUCT FOR YOUR EQUIPMENT OR INSTALLATION REQUIREMENTS. SHOULD FURTHER INFORMATION NOT COVERED BY THESE INSTRUCTIONS BE REQUIRED, PLEASE CONTACT LARSON ELECTRONICS BY EMAIL AT SALES@LARSONELECTRONICS.COM OR BY PHONE AT 1-877-348-9680 FOR FURTHER ASSISTANCE.

PLEASE VISIT LARSONELECTRONICS.COM FOR **WARRANTY** AND **RETURN** INFORMATION.