Larson Electronics LLC www.LarsonElectronics.com sales@larsonelectronics.com
9419 E US HWY 175, Kemp, TX 75143 - P: (800) 369-6671 - F: (903) 498-3364

RL-8X-BATT

TO CHANGE THE BATTERY

The battery is not designed to be “swapped out” in the field. It can be done, but it is not designed like a cordless drill, where you just snap it in and out.

1. Remove the four screws holding the top cover in place on the rear of the main housing. This is the squared section. The 4 screws can be seen when you turn the light upside down. Once the top cover is removed, you will see the battery pack.
2. The battery pack consists of 6 cells welded together. A single Molex style connector brings power from the battery to the bulb. Disconnect this connector and remote the battery pack as a whole. Double sided tape secures the battery pack. Be sure that if the tape has lost its adhesion that you replace it when you replace the battery pack.
3. Replace the battery pack, reconnect the power and replace the top cover.

Lithium ion batteries have a very long life. You should not need to replace the battery pack very often.