Male or Female Deutsch Connector Whip

Instruction Manual

Thank you for purchasing the C-MFDC Male or Female Deutsch Connector Whip, follow these wiring instructions to begin using the product.

NOTE: Make sure all power to desired wiring location is turned OFF.

Identify the positive and negative lines on the connector via color – Positive = Red, **Negative** = Black

- Then use wire strippers or a similar tool to pull back or remove necessary wire tubing to ensure you have the desires amount of wire available to work with.
- Attach the positive and negative wires to the correlating polarities of the attaching wires.
- Use a wire cap, solder etc. *(Recommended) Heat wrap the area between the wiring and housing to ensure a better dust and moisture seal.* to securely connect both wires to your desired area.
- Restore power.

Males need to be connected to a female Deutsch connector and vice versa.

For info on warranty and returns please visit our website: www.Larsonelectronics.com