

Replacement Polycarbonate Lens Instruction Manual

Do not attempt installation until you are familiar with all warnings, precautions, and procedures outlined within this instruction sheet.

WARNING:

READ CAREFULLY BEFORE INSTALLING FIXTURE. RETAIN THESE INSTRUCTIONS FOR FUTURE REFERENCE. CRITICAL SAFETY INSTRUCTIONS:

- RISK OF FIRE OR ELECTRIC SHOCK. IF YOU ARE UNFAMILIAR WITH ANY TERMS USED IN THIS INSTRUCTION MANUAL, DO NOT ATTEMPT INSTALLATION. CONTACT A QUALIFIED ELECTRICIAN.
 - BE CERTAIN ELECTRICAL POWER IS OFF BEFORE AND DURING INSTALLATION AND MAINTENANCE.
 - TO PREVENT WIRING DAMAGE OR ABRASION, DO NOT EXPOSE WIRING TO EDGES OF SHEET METAL OR SHARP OBJECTS. SUITABLE FOR DAMP LOCATIONS.
-

LENS REPLACEMENT

1. Loosen set screw from base handle.
2. Pull handle away from plastic encasing tube.
3. As handle is pulled away, the seated bulb will slide out from the polycarbonate encasing tube.
4. The bulb is held in place with 2 end caps.
5. Lay handle and bulb assembly on a table.
6. Disconnect cable connecting the two end handles.
7. Slide old tube out and replace with new tube.
8. Reconnect cable removed in **Step 6**
9. Slide entire assembly back into plastic encasing tube.
10. Replace handle and tighten set screw.

Should further information not covered by these instructions be required, please contact Larson Electronics at 1-800-369-6671 or sales@larsonelectronics.com for further assistance.

Please visit LarsonElectronics.com for **Warranty** and **Return** information.