

LED6W-GNM-SW Instruction Guide

LED Work Light w/ Goose Neck Magnetic Mount - Inline Switch

Thank you for your purchase of the Larson Electronics LED6W-GNM series LED light. This light is completely assembled, tested and ready for installation when shipped from the factory. Please follow the steps below in order to operate and maintain this product.

IMPORTANT

READ CAREFULLY BEFORE OPERATING THIS FIXTURE. SAVE THESE INSTRUCTIONS FOR FUTURE REFERENCE. IF UNSURE ABOUT ANY PART OF THESE INSTRUCTIONS, CONSULT A QUALIFIED ELECTRICAL PROFESSIONAL.

WARNING: OPERATE ONLY AT THE VOLTAGE LISTED ON THE PRODUCT LABEL. DO NOT OPERATE IN CLOSE PROXIMITY OF COMBUSTIBLE OR FLAMMABLE MATERIALS. NEVER LOOK DIRECTLY AT LIGHT WHEN ON. DO NOT SHINE LIGHT INTO THE FACE OF SOMEONE ELSE.

WARNING: CONSULT A QUALIFIED ELECTRICAL PROFESSIONAL/ELECTRICIAN TO INSTALL THIS DEVICE IN ACCORDANCE WITH APPROPRIATE LOCAL AND NEC CODES AND REGULATIONS.

WARNING: TO BE INSTALLED AND/OR USED IN ACCORDANCE WITH APPROPRIATE ELECTRICAL CODES AND REGULATIONS.

WARNING: DEVICE IS SUITABLE FOR INSTALLATION IN WET LOCATIONS; GFCI PROTECTION RECOMMENDED.

WARNING: ALTHOUGH FIXTURE IS WATERPROOF, IT IS NOT DESIGNED OR INTENDED TO BE SUBMERGED.

WARNING: DO NOT ALLOW LINE VOLTAGE WIRES TO BECOME SUBMERGED!

- IP67 RATED; SUITABLE FOR WET LOCATIONS (ALTHOUGH FIXTURE IS WATERPROOF, IT IS NOT DESIGNED OR INTENDED TO BE SUBMERGED).
- ALL OUTDOOR INSTALLATIONS AND INDOOR INSTALLATIONS NEAR A WET LOCATION REQUIRE THE USE OF A GFCI DEVICE FOR SAFETY, ACCORDING TO THE NATIONAL ELECTRICAL CODE® (NEC).
- KEEP AWAY FROM FLAMMABLE OBJECTS. DO NOT POSITION WITHIN ONE (1) INCH OF ANY COMBUSTIBLE MATERIALS.
- IF DROPPED OR DAMAGED, THE UNIT MAY NO LONGER BE WATERPROOF AND SHOULD BE REPLACED.
- TO AVOID HAZARDS TO CHILDREN, ACCOUNT FOR ALL PARTS AND DESTROY PACKING MATERIALS.
- PEOPLE WITH PACEMAKERS SHOULD CONSULT THEIR PHYSICIAN(S) BEFORE USE. ELECTROMAGNETIC FIELDS IN CLOSE PROXIMITY TO HEART PACEMAKER COULD CAUSE PACEMAKER INTERFERENCE OR PACEMAKER FAILURE.
- KEEP FINGERS AWAY FROM MAGNET WHEN MOUNTING AS INJURY COULD OCCUR.

INSTALLATION

MOUNTING

Mount to any flat metal surface capable of holding the weight of the light. It can be mounted in any direction. When removing, do not drag the magnetic base to disconnect, as it may scratch the surface/paint. The magnet provides 200lb. grip magnetic force.

LIGHT ADJUSTMENT

Position the flexible goose-neck at any angle and the lamp will hold its position. The double ball joint bracket provides adjustability while keeping the goose-neck in place. Loosen the ball joint to rotate the light 360° and tilt or pivot 180°. Tighten the ball joint once the desired position is achieved.

WIRING

Check to ensure the deutsch connector is plugged into the back of the light and plug the unit into compatible outlet providing proper voltage listed on the product label. Improper voltage could cause the unit to fail, voiding warranty. The light is "instant-on" and will turn on once power is supplied.

Voltage Models: 120-240V AC **OR** 12-24V DC (Two separate models. Check product label for voltage.)

Once connected to a power supply, use the switch on the back to turn the light on or off.

MAINTENANCE

If the lens becomes dirty, wipe down with a mild soap and water solution.

It is recommended to occasionally inspect the unit for any defects and to ensure the cable is not frayed and is gripping tightly in all points of cable contact.

TROUBLESHOOTING

Refer to the guide below or contact the manufacturer if the fixture does not function properly.

- Is the correct line voltage being supplied?
- Is the light properly grounded?
- Is the deutsch connector properly attached?

Should further information not covered by these instructions be required, please contact Larson Electronics at 1-800-369-6671 for further assistance.

Please visit LarsonElectronics.com for **Warranty** and **Return** information.