

Instruction Manual

Replacement Lamp for Explosion Proof Pilot Lights


Do not attempt installation until you are familiar with all warnings, precautions, and procedures outlined within this instruction sheet.

LAMP REPLACEMENT

To replace the lamp, unscrew the lens/guard assembly. Replace the lamp **only** with one of exactly the same type and rating. The lens assembly threads should be lubricated occasionally to prevent from binding.

Damaged or worn parts should be replaced immediately to ensure the safety of the system. Refer to the Parts Drawing below. Consult Larson Electronics for specific part numbers.

PARTS DRAWING



THESE INSTRUCTIONS MAY NOT COVER ALL DETAILS OR VARIATIONS OF THIS PRODUCT FOR YOUR EQUIPMENT OR INSTALLATION REQUIREMENTS. SHOULD FURTHER INFORMATION NOT COVERED BY THESE INSTRUCTIONS BE REQUIRED, PLEASE CONTACT LARSON ELECTRONICS BY EMAIL AT SALES@LARSONELECTRONICS.COM OR BY PHONE AT 1-800-369-6671 FOR FURTHER ASSISTANCE.

PLEASE VISIT LARSONELECTRONICS.COM FOR WARRANTY AND RETURN INFORMATION.