

Metal Wire Guard for EPL-HB-150LED-RT and EPL-LED-150W-RT Series Instruction Manual

The EPL-HB-150LED-RT-SP0120 is a field attachable wire guard constructed of non-sparking aluminum. This unit attaches to existing fixtures via six thru-holes, three per side, and is securely fastened to the light fixture. The wire guard protects the glass lens on existing explosion proof fixtures from impacts that may damage the lens.

MOUNTING

Caution: To avoid personal injury, disconnect power to the light and allow the unit to cool down before performing maintenance.

- Align holes on wire guard to holes on light fixture.
- Wire guard can be mounted in any orientation.
- Use the included bolts to mount wire guard to fixture.

MAINTENANCE

Warning: No user serviceable parts inside of fixture. Risk of electric shock. Removal of the lens will void the warranty.

1. Perform visual, mechanical and electrical inspections on a regular basis. We recommend routine checks to be made on a yearly basis. Frequency of use and environment should determine this. It is recommended to follow an Electrical Preventive Maintenance Program as described in NFPA 70B: Recommended practice for Electrical Equipment.
2. The lens should be cleaned periodically as needed to ensure continued photometric performance. Clean the lens with a damp, non-abrasive, lint-free cloth. If not sufficient, use mild soap or a liquid cleaner.
3. Inspect the cooling fins on the luminaire to ensure that they are free of any obstructions or contamination (i.e. excessive dust build-up). Clean with a non-abrasive cloth if needed.
4. Do not operate if the lens is cracked or damaged. All fasteners should be properly seated.

Should further information not covered by these instructions be required, please contact Larson Electronics at 1-800-369-6671 or sales@larsonelectronics.com for further assistance.

Please visit LarsonElectronics.com for **Warranty** and **Return** information.