6 Million Candlepower Handheld Spotlight
120-277V AC - 25' Cord - 100 Watts
Instruction Manual

Thank you for your purchase of the HUL-18-110V spotlight. Please follow the steps below in order to operate and maintain this handheld spotlight.

WARNING:

READ CAREFULLY BEFORE OPERATING FIXTURE. RETAIN THESE INSTRUCTIONS FOR FUTURE REFERENCE. CRITICAL SAFETY INSTRUCTIONS:

- **RISK OF Electric Shock** – To avoid electric shock, serious injury or death, be certain all electrical power is disconnected from the supply branch circuit conductors before installing or maintaining this fixture.
- Never place spotlight face down when light is on. Doing so could burn/ignite surfaces such as seats, carpeting, etc. and cause major property damage. Always turn spotlight off when not in use.
- Avoid direct eye exposure the light source when light is on. **DO NOT** shine light into the face of someone else.
- **DO NOT** touch lens of light when on or recently on. The lens/cooling fins will be hot after long periods.
- **DO NOT** allow children to handle or operate this flood light.
- **DO NOT** use this product for other than its intended use.
- **DO NOT** operate in close proximity of combustible or flammable materials.
- **DO NOT** attempt to operate this flood light if cord, plug, lens or any part of the flood light is damaged or corroded.

The HUL-18-110V is shipped with selected Cord Cap, and Beam Configuration. Images shown may vary depending upon options selected.


POWER

1. Connect all deutsch connectors to light and transformer.

2. Run cord and plug transformer into compatible receptacle outputting voltage within range 120-277VAC, 50/60Hz.

Note: *There is no difference in light output between voltages.*

3. This light has a power switch and will illuminate once toggled.



If spotlight gets loose, tighten adjustment screws on trunnion mount.

If spotlight does not illuminate, check deutsch connector, switch, and/or power source.



QUICK DISCONNECT
DEUTSCH CONNECTOR

Keep encapsulated inline transformer box closed during operation. It is not necessary to access the internals unless during maintenance and repair. Maintenance must be performed by a qualified electrician.

DETACHABLE CORDS

- Cord is attached via a weatherproof 2-pin Deutsch connector.
- The cord is detachable by depressing the tab on the top of the connectors. This enables the operator to leave the cord connected to the power source and remove to store the light.
- Additional or replacement cords can be ordered from our website. Contact us for more information.

• IP67 rated waterproof/dust proof
• Impact/Vibration Resistance
• Operating Temperature Range: -40° C to
•105°C 100 Watts

THESE INSTRUCTIONS MAY NOT COVER ALL DETAILS OR VARIATIONS OF THIS PRODUCT FOR YOUR EQUIPMENT OR INSTALLATION REQUIREMENTS. SHOULD FURTHER INFORMATION NOT COVERED BY THESE INSTRUCTIONS BE REQUIRED, PLEASE CONTACT LARSON ELECTRONICS BY EMAIL AT SALES@LARSONELECTRONICS.COM OR BY PHONE AT 1-800-369-6671 FOR FURTHER ASSISTANCE.

PLEASE VISIT LARSONELECTRONICS.COM FOR **WARRANTY** AND **RETURN** INFORMATION.