AC Charger for SLEDB-5-M High Output Strobing LED Beacon Instruction Manual

Do not attempt installation until you are familiar with all warnings, precautions, and procedures outlined within this instruction sheet.

Thank you for your purchase of the Larson Electronics.

WARNING:

READ CAREFULLY BEFORE INSTALLING FIXTURE. RETAIN THESE INSTRUCTIONS FOR FUTURE REFERENCE.
CRITICAL SAFETY INSTRUCTIONS:

- INSTALLATION SHOULD ONLY BE CONDUCTED BY A QUALIFIED ELECTRICIAN IN ACCORDANCE WITH NEC AND ANY RELEVANT LOCAL BUILDING CODES.
- RISK OF FIRE OR ELECTRIC SHOCK. FIXTURE INSTALLATION REQUIRES KNOWLEDGE OF LUMINAIRES ELECTRICAL SYSTEMS. IF NOT QUALIFIED, CONTACT A QUALIFIED ELECTRICIAN.
- BE CERTAIN ELECTRICAL POWER IS OFF BEFORE AND DURING INSTALLATION AND MAINTENANCE.
- MAKE SURE THE SUPPLY VOLTAGE IS THE SAME AS THE RATED LUMINAIRE FIXTURES VOLTAGE.
- TO PREVENT WIRING DAMAGE OR ABRASION, DO NOT EXPOSE WIRING TO EDGES OF SHEET METAL OR SHARP OBJECTS. SUITABLE FOR DAMP LOCATIONS.

The SLEDB-5-M-ACCORD from Larson Electronics is an AC charger that is compatible with the SLEDB-5-M strobing LED beacon. The SLEDB-5-M-ACCORD allows operators to charge existing SLEDB-5-M strobe lights from AC wall plugs.

Voltage

120V and 220-240V available

Charging

- Plug charger into any basic outlet
- Make sure light is on a stable surface
- Do not use if cord is broken or damage
- Charge Light for a max of 5 Hours



Should further information not covered by these instructions be required, please contact Larson Electronics by email sales@larsonelectronics.com or phone at 1-800-369-6671 for further assistance.

Please visit LarsonElectronics.com for **Warranty** and **Return** information.