

HAL-CRNM Series

Before installing, read the following instructions for safe and proper installation.

WARNING: To prevent ignition of hazardous atmospheres, the supply circuit should be disconnected when installing, relamping or performing any maintenance on the fixture.

CAUTION: When installing fixture in hazardous locations, check the operating temperature limits prior to installation to be sure it conforms to the environmental temperature restrictions and NEC classifications. Check the fixture's metal nameplate for temperature (T) ratings.

PENDANT MOUNTING

1. Thread the fixture onto the conduit, sealing around the conduit using approved NEC procedures. Flats are provided at the top of the fixture to tighten with a wrench.
2. After securing to the conduit, tighten the set screw.

WALL MOUNTING

1. Remove the wiring box from the arm and attach box to the mounting surface.
2. Pull leads to the box and through the arm to the wiring chamber.
3. Attach the arm to the wall box.
4. The mounting screws should be tightened in alternate sequence.

CEILING MOUNTING

1. Attach fixture to mounting surface using the two mounting tabs provided.

WIRING THE FIXTURE

1. Remove the wiring access plug. Connect neutral to white fixture wire and line to black fixture wire. Only connect to voltage as identified on product nameplate. Voltage is specified when ordering.
2. Make all wiring connections in accordance with accepted NEC wiring procedures.
3. Be sure any unused wiring entrances are closed with closure plugs.

LAMP INSTALLATION

1. Unscrew globe cover
2. Unthread the glass globe from the fixture.
3. Install lamp. 'No lamp' models will use customer provided LED lamps, incandescent lamps up to 100W, and compact fluorescent lamps.
4. Reinstall glass globe and globe cover.

WARNING: The globe is tempered glass. Do not scratch or chip. Turn the power off before starting installation, repair or relamping.



Should further information not covered by these instructions be required, please contact Larson Electronics at 1-800-369-6671 for further assistance.

Please visit LarsonElectronics.com for **Warranty** and **Return** information.