Replacement Handle for LED25WRE Series Spotlights Instruction Manual

Thank you for your purchase of the Larson Electronics HUL-CPR-HANDLE. Please read and retain these instructions for future reference.

Warning:
These instructions are for the handle only. Please refer to the instruction manual that came with your spotlight for critical safety and operation information.

Installation

Remove old handle by removing the nut at the base of the light holding it to the handle, this will allow you to slide the bolt out and remove the handle. To install the replacement handle on your spotlight, simply line up the mount holes on the bottom of the light with the holes at the top of the new handle, then slide the bolt through all mount holes in the light and handle simultaneously, then secure it in place with the nut on the other side. Be sure light is turned to the desired angle before tightening the nut completely.

DETACHABLE CORDS

- Cord is attached via a weatherproof 2-pin Deutsch connector.
- The cord is detachable by depressing the tab on the top of the connectors. This enables the operator to remove and store the light while leaving the cord connected to the power source.
- Additional or replacement cords can be ordered from our website. Contact us or visit LarsonElectronics.com for more information.



QUICK DISCONNECT
DEUTSCH CONNECTOR

USE AND CARE

Unauthorized modification may impair the function and/or safety of this device and could affect the life of the equipment. Always check for damaged or worn out parts before using the device. Store it in a secure place out of the reach of children when not in use. Inspect for good working condition prior to storage and before re-use.

REPLACEMENT PARTS

The HUL-CPR-HANDLE is designed to provide years of reliable performance. Should the need for replacement parts arise, please contact Larson Electronics.

THESE INSTRUCTIONS MAY NOT COVER ALL DETAILS OR VARIATIONS OF THIS PRODUCT FOR YOUR EQUIPMENT OR INSTALLATION REQUIREMENTS. SHOULD FURTHER INFORMATION NOT COVERED BY THESE INSTRUCTIONS BE REQUIRED, PLEASE CONTACT LARSON ELECTRONICS BY EMAIL AT SALES@LARSONELECTRONICS.COM OR BY PHONE AT 1-877-348-9680 FOR FURTHER ASSISTANCE.

PLEASE VISIT LARSONELECTRONICS.COM FOR **WARRANTY** AND **RETURN** INFORMATION.