Replacement Inline Step-down Transformer for EPL-120/EHL Series
Instruction Manual

Do not attempt installation until you are familiar with all warnings, precautions, and procedures outlined within this instruction sheet.

WARNING:


READ CAREFULLY BEFORE INSTALLING. RETAIN THESE INSTRUCTIONS FOR FUTURE REFERENCE. CRITICAL SAFETY INSTRUCTIONS:

- TO PREVENT RISK OF ELECTRICAL SHOCK DEACTIVATE/DISCONNECT POWER SUPPLY BEFORE INSTALLING.
- THIS UNIT SHOULD BE INSTALLED BY QUALIFIED TECHNICIANS IN STRICT ACCORDANCE WITH THE NATIONAL ELECTRICAL CODE (NEC) AND ANY STATE OR LOCAL REQUIREMENTS.
- VERIFY THAT THE SUPPLY VOLTAGE AGREES WITH FIXTURE RATING AS INDICATED ON NAMEPLATE. ALL LOCAL AND NATIONAL ELECTRICAL/BUILDING CODES MUST BE FOLLOWED WHEN INSTALLING THIS UNIT. FOR CODE INTERPRETATION, CONSULT YOUR LOCAL AUTHORITY. PRODUCT MUST BE USED OUTSIDE HAZARDOUS AREA.
- ALL WIRING CONNECTIONS SHOULD BE CAPPED WITH UL APPROVED WIRE CONNECTORS.
- ALLOW FIXTURE TO COOL BEFORE HANDLING.
- DO NOT TOUCH INDIVIDUAL ELECTRICAL COMPONENTS AS THE CAN CAUSE ESD, SHORTEN LAMP LIFE, OR ALTER PERFORMANCE.
- TO PREVENT WIRING DAMAGE OR ABRASION, DO NOT EXPOSE WIRING TO EDGES OF SHEET METAL OR SHARP OBJECTS. SUITABLE FOR DAMP LOCATIONS.
- THE CORD MUST BE ROUTINELY CHECKED FOR CUTS, BREAKS, OR ANY SEVERE ABRASIONS, AND IF ANY ARE FOUND, THE CORD MUST BE REPLACED BEFORE RESUMING USE OF THE HANDLAMP.

INSTALLATION

1. Disconnect and remove unit from hazardous area.
2. Open enclosure to reveal transformer inside.
3. Make note of connections.
4. Disconnect wiring and remove.
5. Place new enclosure and wire as before.
6. Ensure all wiring is snug and secure.
7. Test for proper function *OUTSIDE HAZARDOUS AREA*.
8. Replace top lid of enclosure.

This light is “instant-on” and will illuminate once power is supplied to the unit.



USE AND CARE

Always check damaged or worn out parts before using the work light. Broken parts may affect operation. When not in use, store work light in a secure place. Inspect it for good working condition prior to storage and before re-use.

Should further information not covered by these instructions be required, please contact Larson Electronics at 1-800-369-6671 or sales@larsonelectronics.com for further assistance.

Please visit LarsonElectronics.com for **Warranty** and **Return** information.