

Lens Replacement Kit for HALSS Series Instruction Manual

Do not attempt installation until you are familiar with all warnings and procedures outlined within this instruction sheet.

WARNING:

READ CAREFULLY BEFORE INSTALLING FIXTURE. RETAIN THESE INSTRUCTIONS FOR FUTURE REFERENCE.

CRITICAL SAFETY INSTRUCTIONS:


To avoid the risk of fire, explosion or electric shock, this product should be installed, inspected and maintained by a qualified electrician only, in accordance with all applicable electrical codes.

BE CERTAIN ELECTRICAL POWER IS OFF BEFORE AND DURING MAINTENANCE.

INSTALLATION

Turn off power supply. Allow the fixture to cool. Remove fixture from mounting location if necessary.

1. Loosen 8 latches to release front lens from fixture. Keep hold of lens when removing!
2. Remove old lens.
3. Place new lens assembly and secure to light fixture.
4. Tighten 8 latches to secure front lens.
5. Check to ensure all latches are secure.



USE AND CARE

Perform visual, mechanical and electrical inspections on a regular basis. We recommend routine checks to be made on a yearly basis. Frequency of use and environment should determine this. It is recommended to follow an Electrical Preventive Maintenance Program as described in NFPA 70B: Recommended practice for Electrical Equipment.

WARRANTY

Should further information not covered by these instructions be required, please contact Larson Electronics at 1-800-369-6671 or sales@larsonelectronics.com for further assistance.

Please visit LarsonElectronics.com for **Warranty** and **Return** information.