

Boat Mount for HUL-LED25WRE Series Handheld Spotlights Instruction Guide

Thank you for your purchase of the Larson Electronics HUL-LED25WRE-SP1154 Boat Mount for HUL-LED25WRE Series Handheld Spotlights. Please follow the steps below in order to operate and maintain this product.

The HUL-LED25WRE-SP1154 from Larson Electronics is a Boat Mount for HUL-LED25WRE Series Spotlights that provides secure mounting to boats for convenient lighting while on the water.

INSTALLATION

- Test fit your light to the mount prior to installation to ensure a proper fit. The mount should be oriented with the pin holes at the top, upward most part of the light handle.
- Attach boat mount to your surface using suitable hardware for the location. There are pre-drilled holes on the mount for screws to pass through.

Once mounted in the desired location, follow steps for mounting light:

1. Place light up against mount with the light head facing away from you. Mount is designed to hold light by the handle.
2. There is a pin attached to a short chain. Once light is in place, slide pin through holes near the handle to secure light in place. Make sure the pin is pushed far enough through to create a tight fit and prevent the pin from sliding out.
3. To remove and use light, simply slide pin out and remove light from the mount. It may be necessary to pinch the ends of the mount to help release the pin.

Always apply the pin when light is attached to prevent unintentional dismount of light.

If mount swivels, tighten center bolt to secure.



THESE INSTRUCTIONS MAY NOT COVER ALL DETAILS OR VARIATIONS OF THIS PRODUCT FOR YOUR EQUIPMENT OR INSTALLATION REQUIREMENTS. SHOULD FURTHER INFORMATION NOT COVERED BY THESE INSTRUCTIONS BE REQUIRED, PLEASE CONTACT LARSON ELECTRONICS BY EMAIL AT SALES@LARSONELECTRONICS.COM OR BY PHONE AT 1-800-369-6671 FOR FURTHER ASSISTANCE.

PLEASE VISIT LARSONELECTRONICS.COM FOR **WARRANTY** AND **RETURN** INFORMATION.