Instruction Manual

WAL-RL-60LED-M

THANK YOU FOR PURCHASING THE WAL-RL-60LED-M RECHARGEABLE WORK LIGHT. SAVE THESE INSTRUCTIONS.



Please read these instructions before using your work light. Be sure to charge the work light before the first use.

- CAUTION: Do not use this work light in explosive atmospheres, near flammable liquids, or where explosion-proof lamps are required. Do not immerse in water.
- CAUTION: For light duty work only.

CHARGING

INITIAL USE

Fully charge the work light before the first use. If the battery is new or has been unused for several months, several charge and discharge cycles may be needed to reach full battery capacity. To reach maximum performance, run the light to completely discharge the battery and then recharge. Each charge cycle will extend the operation time until maximum capacity is achieved. The charge time for maximum capacity is approximately 8 hours.

REGULAR USE

- Use only the supplied AC or DC charging adapter.
- For best performance, charge the work light when the LED's start to dim.
- Connect the AC power adapter to the light. The red indicator will light.
- The red light indicates the work light is being charged. The red light remains on until the battery is fully charged. At full charge, the light turns off. The total time to full charge varies depending on the remaining charge in the battery pack.
- Keep the work light plugged into the charger to maintain a trickle charge.

TIPS TO EXTEND BATTERY LIFE

- The work light's Nickel Metal Hydride internal battery does not have any recharge memory effect. Charging the work light often helps extend its useful life.
- A new work light or one that has not been used for a long period of time may not accept a full charge initially. This is normal and does not indicate a problem. Fully discharge and then charge the unit several times to condition the battery pack for full capacity. As the battery pack capacity increases the charge time shortens.
- Charge the unit after each use, whether the work light is fully discharged or not.
- Store the work light at room temperature

OPERATION

TURNING THE WORK LIGHT ON/OFF

The work light has a 2 position rocker switch to activate either the floodlight or spotlight.

FLOODLIGHT

- Press the Rocker Switch to the Up position to activate the floodlight

SPOTLIGHT

- Press the Rocker Switch to the Down position to activate the spotlight

TURNING THE WORK LIGHT OFF

- The center position of the Rocker Switch turns the light off

INTEGRATED MAGNETS AND MAGNETIC HOOK

- The work light has two integrated magnets, one in the body of the light and the other at the tip. These magnets will support the weight of the light when magnetically attached to a ferrous metal surface. The removable Magnetic Hook can also be attached to either of the integrated magnets and offers additional hands-free options.

CLEANING

- Disconnect the light from the power source
- Wipe with a clean dry soft cloth
- Do not use any solvent or abrasive cleaners

WARRANTY

For a complete copy of the warranty, visit www.larsonelectronics.com or contact us. Retain your receipt for proof of purchase.