

Micro Transformer

1000 VA – 208V Input Voltage - 120V Output Voltage

Instruction Manual

Do not attempt operation until you are familiar with all warnings, precautions, and procedures outlined within this instruction sheet. Read carefully before operating. Retain these instructions for future reference.

WARNING!

- TO PREVENT RISK OF ELECTRICAL SHOCK DEACTIVATE/DISCONNECT POWER SUPPLY BEFORE INSTALLING.
- FOR SAFETY AND WARRANTY CONCERNS, THIS FIXTURE SHOULD BE INSTALLED BY QUALIFIED TECHNICIANS IN STRICT ACCORDANCE WITH THE NATIONAL ELECTRICAL CODE (NEC) AND ANY STATE OR LOCAL REQUIREMENTS.
- VERIFY THAT THE SUPPLY VOLTAGE AGREES WITH TRANSFORMER RATING AS INDICATED ON NAMEPLATE. ALL LOCAL AND NATIONAL ELECTRICAL/BUILDING CODES MUST BE FOLLOWED DURING INSTALLATION. FOR CODE INTERPRETATION, CONSULT YOUR LOCAL AUTHORITY.

The MMT-208V-1000VA-120V from Larson Electronics is a 208V single phase primary voltage micro transformer that is powerful, reliable and innovatively designed. With high-quality silicon steel laminations providing optimal performance, the MMT-208V-1000VA-120V provides increased reliability and protection against critical equipment failures. This micro transformer features an innovative design with a unique terminal block design that allows for a quick and easy hook up along with the ability to easily install fuse clips to the unit. The uniquely designed molded coil covers give this micro transformer superior cooling abilities and a sleek appearance.

Important Installation Notes

1. Torque all terminal screws between 12 and 14 in-lbs.
2. For all bare wire connections, the recommended wire size range is 18 AWG to 14 AWG for solid wire, and 14 AWG for stranded. A ring or spade connector must be used if using a wire size outside the range listed above.
3. Ensure mounting screws used for transformer installation (not supplied) are properly sized for transformer weight.
4. When mounting fuse clips, remove the appropriate captive washer screw(s) from terminal block and install fuse clip(s) and new terminal screw(s).
5. Please refer to wiring instructions for connection details.

THESE INSTRUCTIONS MAY NOT COVER ALL DETAILS OR VARIATIONS OF THIS PRODUCT FOR YOUR EQUIPMENT OR INSTALLATION REQUIREMENTS. SHOULD FURTHER INFORMATION NOT COVERED BY THESE INSTRUCTIONS BE REQUIRED, PLEASE CONTACT LARSON ELECTRONICS BY EMAIL AT SALES@LARSONELECTRONICS.COM OR BY PHONE AT 1-800-369-6671 FOR FURTHER ASSISTANCE.

PLEASE VISIT LARSONELECTRONICS.COM FOR **WARRANTY** AND **RETURN** INFORMATION.