

Replacement E26 Lamp Socket for the HAL-MJ Series Lights Instruction Manual


Do not attempt installation until you are familiar with all procedures outlined within this instruction sheet.

INSTALLATION

- Before installation or service of this fixture, **TURN OFF ELECTRICITY**.
- Wiring needs to comply with National and Local Electric Codes.
- The installation should be done by a qualified electrician.
- When a grounding grid is supplied with the fixture, lock nuts must be used on in-coming conduit to ensure continuity of grid/conduit system. Lock nuts sold separately.

The HAL-MJ-SP0104 is a Replacement E26 Lamp Socket for the HAL-MJ series Lights.

1. Disconnect electricity going to lamp.
2. Remove guard. Turn guard counter-clockwise to loosen and unscrew from base.
3. Remove globe. Turn globe counter-clockwise to loosen and unscrew from base.
4. Remove lamp.
5. Remove screws holding lamp assembly to mount.
6. Disconnect electrical wires to lamp socket.
7. Remove the two screws holding lamp socket and remove lamp socket.
8. Insert new lamp socket and tighten screws.
9. Wire lamp socket accordingly.
10. Re-attach lamp assembly to mount.
11. Install lamp.
12. Install globe and tighten to ensure seal.
13. Install guard.



WIRING

1. **TURN OFF ELECTRICITY**
2. Connect black lead to incoming power.
Connect white lead to incoming neutral.
Connect incoming ground wire to ground lug in fixture.

Make all connections in accordance with accepted N.E.C. procedures.

LAMP INSTALLATION

For incandescent series use matching 100w A19 max. with glass globe.

For LED series use matching lamp designated on fixture label. 10w A19 LED (P/N: LED-A19-10-E26)

HAZARDOUS LOCATION WARNING

1. TO PREVENT RISK OF ELECTRICAL SHOCK DEACTIVATE/DISCONNECT POWER SUPPLY BEFORE INSTALLING OR RELAMPING FIXTURE.
2. TO REDUCE RISK OF FIRE OR EXPLOSION, DO NOT INSTALL WHERE MARKED OPERATING TEMPERATURE EXCEEDS THE IGNITION TEMPERATURE OF THE HAZARDOUS ATMOSPHERES.
3. THIS FIXTURE SHOULD BE INSTALLED BY QUALIFIED TECHNICIANS IN STRICT ACCORDANCE WITH THE NATIONAL ELECTRICAL CODE AND ANY LOCAL REQUIREMENTS.

THESE INSTRUCTIONS MAY NOT COVER ALL DETAILS OR VARIATIONS OF THIS PRODUCT FOR YOUR EQUIPMENT OR INSTALLATION REQUIREMENTS. SHOULD FURTHER INFORMATION NOT COVERED BY THESE INSTRUCTIONS BE REQUIRED, PLEASE CONTACT LARSON ELECTRONICS BY EMAIL AT SALES@LARSONELECTRONICS.COM OR BY PHONE AT 1-800-369-6671 FOR FURTHER ASSISTANCE.

PLEASE VISIT LARSONELECTRONICS.COM FOR **WARRANTY** AND **RETURN** INFORMATION.