


Opaque Cover for 1 Lamp 4ft EPL Models

The polycarbonate lens cover is intended to protect the lamps from paint overspray. Simply replace the polycarbonate lens cover when dirty instead of the glass pyrex lens tubes.

Follow the basic installation steps below.

- 1. Replacing lens:** Grasp one side and pull to remove old lens from lamp fixture.
- 2. Install lens cover:** Start with one side and insert lens under the lip of lamp.
- 3. Attach polycarbonate lens** to the other side under the opposite lip.



A mild soap and water can be used keep the lens clean and clear. If the lens becomes dirty beyond cleaning, the polycarbonate lens can be removed as easily as it was installed.

THESE INSTRUCTIONS MAY NOT COVER ALL DETAILS OR VARIATIONS OF THIS PRODUCT FOR YOUR EQUIPMENT OR INSTALLATION REQUIREMENTS. SHOULD FURTHER INFORMATION NOT COVERED BY THESE INSTRUCTIONS BE REQUIRED, PLEASE CONTACT LARSON ELECTRONICS BY EMAIL AT SALES@LARSONELECTRONICS.COM OR BY PHONE AT 1-800-369-6671 FOR FURTHER ASSISTANCE.

PLEASE VISIT LARSONELECTRONICS.COM FOR **WARRANTY** AND **RETURN** INFORMATION.