

Incandescent Trouble Light / Hand Lamp / Drop Light - 16/3 SOOW Cord Instruction Manual

Do not attempt operation until you are familiar with all warnings, precautions, and procedures outlined within this instruction sheet. Read carefully before operating. Retain these instructions for future reference.

WARNING:

- KEEP LIGHTED LAMP AWAY FROM COMBUSTIBLES.
- DO NOT TOUCH HOT LENS GUARD OR ENCLOSURE.
- DO NOT LOOK DIRECTLY AT LIGHTED LAMP.
- KEEP LAMP AWAY FROM MATERIALS THAT MAY BURN.
- USER SHOULD BE TRAINED IN THE PROPER USE AND MAINTENANCE OF THIS DEVICE.

USING THE HAND LAMP

1. Position light head in desired location using built-in hook.
2. Run cable and attach power cord from light to **voltage listed on product label**.

WARNING: *This hand lamp operates with 220V, 230V, 240V AC 50/60 Hz. Check product label for correct voltage! Damage from improper voltage may not be covered by warranty.*

OPERATION

The lamp in this hand lamp is controlled via the power switch and will illuminate once toggled.

A 15 amp (5-15R) receptacle allows equipment to be plugged in to the lamp further extending its use. The receptacle will continue to function with the light turned off. **DO NOT** exceed max amperage of 15 amps! **Power output reflects input voltage.**

LAMP REPLACEMENT

1. Apply pressure to side of cage allowing it to open.
2. Remove old bulb.
3. Replace with matching bulb.
4. Close cage.

Note: Over tightening lamp can deform threads or cause damage.

USE AND CARE

Unauthorized modification may impair the function and/or safety of the work light and could affect the life of the equipment. Always check damaged or worn out parts before using the work light. When work light is not in use, store it in a secure place out of the reach of children. Inspect for good working condition prior to storage and before re-use.

REPLACEMENT PARTS

The WAL-DL-220V is designed to provide years of reliable lighting performance. Should the need for replacement parts arise, please contact Larson Electronics at the contact information below.

THESE INSTRUCTIONS MAY NOT COVER ALL DETAILS OR VARIATIONS OF THIS PRODUCT FOR YOUR EQUIPMENT OR INSTALLATION REQUIREMENTS. SHOULD FURTHER INFORMATION NOT COVERED BY THESE INSTRUCTIONS BE REQUIRED, PLEASE CONTACT LARSON ELECTRONICS BY EMAIL AT SALES@LARSONELECTRONICS.COM OR BY PHONE AT 1-800-369-6671 FOR FURTHER ASSISTANCE.

PLEASE VISIT LARSONELECTRONICS.COM FOR **WARRANTY** AND **RETURN** INFORMATION.

