ML-1-200lb-BC Flood Light with 200lb Grip Magnetic Base - Spring Battery Clamps Instruction Manual

Thank you for your purchase of the ML Series Hand-held Utility Light with Magnetic Base. These instructions will cover how to operate the light as well as bulb replacement.

The light features a magnetic base that allows it to attach to any metal surface – the mount has gripping power up to 200lbs. When removing, do not drag the magnetic base to disconnect, as it may scratch the surface/paint.

OPERATION

- Place on metal surface.
- Adjust tightness of tilt movement using the tightening bolts on sides of base hinge.
- Clip camps onto a power source.
- On/off toggle switch located on the back of the lamp housing controls power to the lamp.



NOTE: ***Check for proper voltage before use!*** *Power options range from 12v DC to 24v DC. Each model requires a specific voltage and may not be variable.*



BULB REPLACEMENT (Non-LED Round Model)

To replace the bulb remove the screw on the bottom of the face ring. Take the face ring off of the lamp and pull the bulb out of the socket freeing it form the spring fasteners. Place the new bulb in its socket and replace face ring.

