




Wiring Diagram

WARNING: DO NOT SERVICE WHILE ENERGIZED!

MT-CTX-24V-100VA-240V



Low Voltage (LV)
(Primary)
24V

Install Supplied Jumpers
Between Terminals
3-2

Lines
Connect to
1, 4

High Voltage (HV)
(Secondary)
240

Install Supplied Jumpers
Between Terminals
3-2

Lines
Connect to
1, 4