5W Battery-powered LED Strobe Light
Visible up to 500' at Night - Colored Lens - Wireless Remote
Instruction Manual

Thank you for your purchase of the Larson Electronics LEDB-6R-M-WR.

WARNING:

READ CAREFULLY BEFORE INSTALLING FIXTURE. RETAIN THESE INSTRUCTIONS FOR FUTURE REFERENCE.
CRITICAL SAFETY INSTRUCTIONS:

- INSTALLATION SHOULD ONLY BE CONDUCTED BY A QUALIFIED ELECTRICIAN IN ACCORDANCE WITH NEC AND ANY RELEVANT LOCAL BUILDING CODES.
- RISK OF FIRE OR ELECTRIC SHOCK. FIXTURE INSTALLATION REQUIRES KNOWLEDGE OF FIXTURE'S ELECTRICAL SYSTEMS. IF NOT QUALIFIED, CONTACT A QUALIFIED ELECTRICIAN.
- BE CERTAIN ELECTRICAL POWER IS OFF BEFORE AND DURING INSTALLATION AND MAINTENANCE.
- MAKE SURE THE SUPPLY VOLTAGE IS THE SAME AS THE FIXTURE'S RATED VOLTAGE.
- TO PREVENT WIRING DAMAGE OR ABRASION, DO NOT EXPOSE WIRING TO EDGES OF SHEET METAL OR SHARP OBJECTS. SUITABLE FOR DAMP LOCATIONS.

IMPORTANT

READ CAREFULLY BEFORE INSTALLING THIS FIXTURE. SAVE THESE INSTRUCTIONS FOR FUTURE REFERENCE. THE LEDB-6R-M-WR MUST BE WIRED IN ACCORDANCE WITH NATIONAL ELECTRICAL CODE AND ALL APPLICABLE LOCAL CODES. PROPER GROUNDING IS REQUIRED FOR SAFETY.

WE STRONGLY ENCOURAGE ONLY A LICENSED ELECTRICIAN INSTALL, OPERATE AND MAINTAIN THIS PRODUCT. IF YOU ARE NOT QUALIFIED OR UNFAMILIAR WITH ANY ASPECT OF THIS INSTRUCTION SHEET, CONSULT AN ELECTRICIAN. THERE ARE NO SERVICEABLE PARTS INSIDE.

WARNING: MAKE SURE POWER IS TURNED **OFF** BEFORE STARTING THE INSTALLATION OR PERFORMING ANY MAINTENANCE.

RISK OF FIRE/ELECTRIC SHOCK – DISCONNECT POWER AT BREAKER BEFORE INSTALLING OR SERVICING.
RISK OF PERSONAL INJURY – FIXTURE MAY BECOME UNSTABLE OR DAMAGED IF NOT INSTALLED PROPERLY.
RISK OF BURN – ALLOW FIXTURE TO COOL BEFORE SERVICING.

Never place spotlight face down when light is on. Doing so could burn/ignite surfaces such as seats, carpeting, etc. and cause major property damage. Always turn spotlight off when not in use.

Avoid direct eye exposure the light source when light is on. **DO NOT** shine light into the face of someone else.
DO NOT touch lens of light when on or recently on. The lens/cooling fins will be hot after long periods.
DO NOT allow children to handle or operate this light.
DO NOT use this product for other than its intended use.
DO NOT operate in close proximity of combustible or flammable materials.
DO NOT attempt to operate this light if cord, plug, battery, lens or any part of the light is damaged or corroded.

The Larson Electronics LEDB-6R-M-WR Battery-powered LED Strobe Light is a compact signaling device with portable applications. This 5-watt light provides a highly effective alternative to beacons that require wiring and special permanent mounting. Powered by a lithium-ion battery and equipped with a wireless remote, the unit is available with an AC charger or a DC charger.

CHARGER

The LEDB-6R-M-WR comes with an AC charger that operates on 120V AC and features a 5-10P cord cap or a DC charger with a cigarette plug for low voltage connections.

MOUNTING

This LED strobe light has a magnetic base for seamless, quick mounting without tools.

REMOTE

- Remove white cover from receiver
- Press and hold the white button on receiver
- Light will begin to flash, it will flash once and pause, then flash twice and pause, then three times and pause, etc...
- The number of flashes indicates the modes. Two flashes is momentary (on when holding the button off when it's let go) and three flashes is maintained (on button press will turn it on, another button press will turn it off). All the other modes are for different remotes so you only want 2 or 3 flashes. Once it's flashes the desired amount of times let the button go and press it again. The light should stay lit now.
- Press the button on the remote, the light in the receiver should flash. Do this three times to pair the remote. The light should turn off and the remote should now be paired.

MAINTENANCE

There are no serviceable parts inside the fixture. However, it is good practice to routinely clean and check the fixture for proper function.

- Disconnect power running to the lamp and be sure the fixture is cool to the touch.
- Use a non-abrasive glass cleaning solution to clean the lens.

Note: *It is not necessary to open the fixture and clean or touch the LED's.*

USE AND CARE

Unauthorized modification may impair the function and/or safety of this device and could affect the life of the equipment. Always check for damaged or worn out parts before using the device. Store it in a secure place out of the reach of children when not in use. Inspect for good working condition prior to storage and before re-use.

REPLACEMENT PARTS

The LEDB-6R-M-WR is designed to provide years of reliable performance. Should the need for replacement parts arise, please contact Larson Electronics.

THESE INSTRUCTIONS MAY NOT COVER ALL DETAILS OR VARIATIONS OF THIS PRODUCT FOR YOUR EQUIPMENT OR INSTALLATION REQUIREMENTS. SHOULD FURTHER INFORMATION NOT COVERED BY THESE INSTRUCTIONS BE REQUIRED, PLEASE CONTACT LARSON ELECTRONICS BY EMAIL AT SALES@LARSONELECTRONICS.COM OR BY PHONE AT 1-800-369-6671 FOR FURTHER ASSISTANCE.

PLEASE VISIT LARSONELECTRONICS.COM FOR **WARRANTY** AND **RETURN** INFORMATION.