



IND-RL-HDB-BX9 Replacement Battery

The battery in the IND-RL-HDB-BX9 rechargeable handlamp is located behind the reflector. The lamp needs disassembled to replace the battery

1. Remove the UV lamp from the fixture
Note: DO NOT touch lamps with bare hands. The oils from your skin will degrade the lamp and reduce the lifespan of the lamp. Use gloves when handling the lamp
2. Unbolt the lamp socket bracket. This bracket holds the lamp socket to the housing. Wiring does not need to be disconnected.
3. Unbolt the mirror reflector and remove it from the fixture.
4. Disconnect the power cable to the battery
5. Unbolt the battery tie downs to free the battery
6. Remove existing battery and replace with new battery
7. Reverse steps 1-5 to reassemble the fixture