

Red LED 360 Degree Beacon Kit - 2.4Ghz Wireless Remote

(4) Battery Powered LED Beacons - Magnetic Base


Instruction Manual

Thank you for your purchase of the SL-360-M-WR-R-4X-WP Battery Powered Red LED 360 Degree Beacon kit, the following instructions are intended for this part number only.

Setup

To begin it would be easier if the light was on a non-magnetic surface. You will need to insert 4 AA batteries into the battery carrier. To access the battery compartment unscrew the outer shell of the light. Next pull out the battery carrier from the middle of the reflective compartment and place the 4 batteries according to their corresponding slot.

Return the battery carrier to its position in the center and flip the ON/OFF switch on the base of the light to make sure everything is working properly.



Speed Adjustment

Underneath the battery compartment is a plastic screw used to adjust the speed at which the LED lights flash.

Use a Phillips head screwdriver to turn the screw right to speed it up or left to slow it down. Once you've reached your desired speed, replace the battery carrier in its compartment and re-secure the shell of the light to the base.

Remote

The light features a wireless on/off functionality, which is controlled by a 2.4Ghz wireless remote. This wireless remote has a 50 foot working distance from the light, with no need for wiring or external power sources. Power switch on the bottom of the beacons must be set to ON for wireless remote operations.

USE AND CARE

Unauthorized modification may impair the function and/or safety of this device and could affect the life of the equipment. Always check for damaged or worn out parts before using the device. Store it in a secure place out of the reach of children when not in use. Inspect for good working condition prior to storage and before re-use.

REPLACEMENT PARTS

The SL-360-M-WR-R-4X-WP is designed to provide years of reliable performance. Should the need for replacement parts arise, please contact Larson Electronics.

THESE INSTRUCTIONS MAY NOT COVER ALL DETAILS OR VARIATIONS OF THIS PRODUCT FOR YOUR EQUIPMENT OR INSTALLATION REQUIREMENTS. SHOULD FURTHER INFORMATION NOT COVERED BY THESE INSTRUCTIONS BE REQUIRED, PLEASE CONTACT LARSON ELECTRONICS BY EMAIL AT SALES@LARSONELECTRONICS.COM OR BY PHONE AT 1-877-348-9680 FOR FURTHER ASSISTANCE.

PLEASE VISIT LARSONELECTRONICS.COM FOR **WARRANTY** AND **RETURN** INFORMATION.