



EXPFL-31

Explosion Proof Halogen Flashlight Instruction Manual





Congratulations on the purchase of your new Handheld Waterproof and Explosion Proof Flashlight. Please read these instructions carefully to familiarize yourself with the safe operation and maintenance of your new flashlight. Following these instructions will insure many years of safe and dependable service.

Table of Contents

I. Operating Instructions	2
I.I Assembly	2
I.II Operation	2
II. Bulb Replacement	3
III. Warnings	4

I. Assembly and Operation

I. Assembly

Unscrew the lens cap and install approved 2 "AA" alkaline batteries. Once batteries have been placed, screw the lens cap back on.

II. Operation

This flashlight features a simple push button switch for easy operation. Operators press the switch once to turn on and again to turn off.



II. Bulb Replacement

I. Replacement

Begin by unscrewing the lens cap of the flashlight. The light housing is held together with the lens cap by clicking into place. To separate the the housing and the lens cap simply apply force and pull them apart.

(Note: The bulb is held in place via a screw attached to the lens, upon separation of the housing and lens cap the bulb will be free, be careful not to drop, lose, or break the bulb.)

The bulb is now free to be replaced.



Specifications

Power Source: 2 AA Cells

Bulb/Lamp: Xenon

Bulb/Lamp Life: 15 Hours

Light Output: 13,000 Beam Candlepower

Weight (Without batteries): 2.2 oz.

Replacement Bulb: XPR2AA #20350

Approximate Burn time during continuous use: 3 hours 30 min.

Approximate Burn time during intermittent use: 4 hours 30 min

Product Features

- UL Division 1 & 2 Listed
- Non-Conductive
- Passes 30 foot drop onto concrete
- 13,000 Candle Power
- Pushbutton Switch
- Pre-focused spot beam
- Key Ring
- Xenon Bulb
- Submersible to 100ft
- Pocket size
- Fits Helmet Clips



III. Safety Warnings and Ratings

For personal safety, always follow the safety instructions in this manual to ensure safe and long-term use. Failing to do so can result in damage to the product or serious bodily injury.

I. Safety Warnings

Never place flashlight face down when light is on or is still hot from recent use. Doing so could burn/ignite surfaces such as seats, carpeting, etc. and cause major property damage. Always turn spotlight off when not in use.

To prevent serious damage to eyesight, never look into the flashlight when light is on. **DO NOT** shine light into the face of someone else.

DO NOT touch the lens of the flashlight when light is on or if it was recently on. The lens will be hot and could cause serious burns.

DO NOT allow children to handle or operate this flashlight.

DO NOT use this product for other than its intended use.

DO NOT operate in close proximity of combustible or flammable materials.

DO NOT attempt to operate this spotlight if cord, plug, battery, bulb or any part of the spotlight is damaged or corroded.

DO NOT remove lens ring.

DO NOT allow metal parts to touch metal contacts on battery as this can cause a short circuit and result in a fire.

II. Ratings

UL: Class I, Div 1, Group C & D / Class I, Div 2
Group A, B, C, D
Class II, Div 2, Group G
Operating Temp T3C
MSHA: Approved

Should further information not covered by these instructions be required, please contact Larson Electronics at **1-800-369-6671** or **sales@larsonelectronics.com** for further assistance.

Please visit LarsonElectronics.com for **Warranty** and **Return** information.