RL-85-HID Battery Replacement

The battery on an RL-85-HID rechargeable spotlight is similar to that of a cordless drill except there is a wire connected between the two. In order to disconnect this wire and replace the battery, follow the steps below.

1. Press in the two tabs toward the base of the light while lifting the light upwards to release the battery.



2. Disconnect the wire connecting the light to the battery by gently pulling up the tab on top of the connector and removing the cord.



3. Connect the spotlight to your new battery. Connect the wire and press the connector in until it securely latches to the battery.



4. Fit the spotlight into the battery until the two tabs release locking it in place.



5. Test your spotlight to ensure proper function.



LARSON ELECTRONICS LLC • 9419 E US HWY 175 • KEMP, TX 75143

p: 1-800-369-6671 • intl: 903-498-3363 • f: 903-498-3364 • sales@larsonelectronics.com