

4 Foot LED Portable LED Flood Light System Instruction Manual

Do not attempt installation until you are familiar with all warnings, precautions, and procedures outlined within this instruction sheet.

WARNING:

READ CAREFULLY BEFORE INSTALLING FIXTURE. RETAIN THESE INSTRUCTIONS FOR FUTURE REFERENCE. CRITICAL SAFETY INSTRUCTIONS:

- Risk of fire or electric shock. If you are unfamiliar with any terms used in this instruction manual, do not attempt installation. Contact a qualified electrician.
- Be certain electrical power is off before and during installation and maintenance.
- Fixtures must be connected to a wiring system with an equipment-grounding conductor.
- Make sure the supply voltage is the same as the rated luminaire fixtures voltage.
- To prevent wiring damage or abrasion, do not expose wiring to edges of sheet metal or sharp objects. Suitable for damp locations.

INSTALLATION

This fixture can be hang mounted via the included straps to suspend the fixture or floor mounted via the support legs on the back of the fixture. If mounting, this fixture must be mounted to an area that can structurally support the load.

With the hanging straps installed on the fixture, mount the drop light in your desired location either vertically or horizontally. Use one or both hanging straps as necessary. Run power to the fixture accordingly.

Caution: Only use voltage as shown on fixture nameplate!

Plug the fixture into the appropriate receptacle. The light on this fixture is “instant-on” and will illuminate once power is supplied.

Voltage: 120/277 VAC 50/60Hz

LAMP REPLACEMENT (LEDT8-28W-V1)

1. Loosen the end cap retaining bolt from the base..
2. Pull the end cap away from the housing.
3. As the end cap is pulled away, the seated bulb can be slid out from the housing body.
4. The bulb is held in place with 2 end cap bulb “spiders”.
5. Lay the bulb assembly on a table.
6. Pull back the individual white plastic spiders on each end of the lamp(s). The bulb will free to remove.
7. Attach the individual white plastic spiders on each end of the new lamp(s) and slide the entire assembly back into the housing body.
8. Replace the end cap and tighten retaining bolt.

Should further information not covered by these instructions be required, please contact Larson Electronics at 1-800-369-6671 or sales@larsonelectronics.com for further assistance.

Please visit LarsonElectronics.com for **Warranty** and **Return** information.