



Larson Electronics LLC www.LarsonElectronics.com sales@larsonelectronics.com
9419 E US HWY 175, Kemp, TX 75143 - P: (800) 369-6671 - F: (903) 498-3364

RL-10-IR

NOTICE

- Do not operate the RL-10-IR in an environment where flammable gases may be present.
- Do not stare directly into the light or shine directly into the eyes of another person as this may cause temporary loss of vision.
- Do not let water enter the case, while the RL-10-IR is both weather and water resistant, it is not designed to be submersible.
- If the RL-10-IR is damaged do not turn on until it has been inspected by an authorized service center.
- Never touch any exposed sections, especially any wires, as this may cause serious injury from high voltage electrical shock.
- Do not operate the flashlight if the front lens is cracked or removed.
- Never disassemble the RL-10-IR, as all parts must be factory serviced to insure proper operation.
- Do not store the light and battery in locations where the temperature may exceed 104 degrees F (40 degrees C) or wet/damp locations of high humidity.
- Should the operating time show significant decrease (even after full charging), battery replacement will be required.
- If the RL-10-IR is to be stored for long periods of time or to prevent accidental operation, remove the battery from the flashlight.
- Do not allow objects or skin to contact the lens after extended operation.
- Do not operate the RL-10-IR during charging stage.
- Due to high intensity discharge characteristics and to prolong bulb life, do not continuously switch the light on and off, and wait 5 minutes before restarting.

FEATURES

- Swivel light head with multiple angle adjustments for different operational requirements.
- Adjustable flood to spot beam pattern using lens focus ring.
- Built in LED indicator inside the battery and, with a full charge, the battery will last as long as 70 minutes.

OPERATING

1. INSTALLING THE BATTERY

Insert the battery in the manner shown on figure A-1. Be sure the battery is fully locked into position.

2. TO REMOVE THE BATTERY

Grasp the battery firmly and press the battery release button (located on side) and pull straight out.

3. TURNING ON

Slide the on/off switch towards the front lens to turn on and backwards towards the battery to turn off.



Larson Electronics LLC www.LarsonElectronics.com sales@larsonelectronics.com
9419 E US HWY 175, Kemp, TX 75143 - P: (800) 369-6671 - F: (903) 498-3364

MAINTENANCE:

- Periodically clean the surface with a cloth (moistened with a mild detergent)
- Clean the front lens after it has cooled with glass cleaner. Use of harsh cleaners may cause discoloration of the surface.
- The RL-10-IR has been designed for maintenance free use. In the event a bulb or other part replacement becomes necessary, please contact Magnalight. Other than battery replacement there are no user serviceable parts.