

EPL-48 & EPL-24 Series Replacement Mounting Bracket Instruction Manual

Do not attempt operation until you are familiar with all warnings, precautions, and procedures outlined within this instruction sheet. Read carefully before operating. Retain these instructions for future reference.

WARNING:

USER SHOULD BE TRAINED IN THE PROPER USE AND MAINTENANCE OF THIS DEVICE.

- INSTALL, OPERATE, AND MAINTAIN TO MEET ALL APPLICABLE CODES.
- DISCONNECT ELECTRICAL POWER BEFORE SERVICING THIS FIXTURE.
- ALLOW FIXTURE TO COOL BEFORE SERVICING.


CAUTION

PROTECT LENS FROM SCRATCHES AND ABRASIONS.

INSTALLATION

1. Remove light fixture from its mounted location (if necessary) and access the back.
2. Remove existing mounting bracket. Loosen the bolt on each side of the bracket and slide off.

Note for models with driver box: If switching to pendant mount; it is not necessary to remove the surface bracket on the side with the driver box.



3. Attach new mount and tighten bolts in desired position. When pendant mounting, take note of NPT position on opposite end. There are three possible positions for rigid pipe.
4. Follow fixture instructions for installing.

AIMING

This lamp can be adjusted by loosening the brackets and repositioning. If pendant mounted or powered via conduit, take lamp position into consideration before finalizing installation.

MAINTENANCE:

Electrical and mechanical inspection of all components must be performed on a regularly scheduled basis, determined by the environment and frequency of use. It is recommended that inspection be performed a minimum of once a year.

Should further information not covered by these instructions be required, please contact Larson Electronics at 1-800-369-6671 or sales@larsonelectronics.com for further assistance.

Please visit LarsonElectronics.com for **Warranty** and **Return** information.