WL-LED-12-M

CAUTION: Read all instructions and warnings before operating.
SAVE THESE INSTRUCTIONS! READ ALL INSTRUCTIONS!

WARNING: To avoid serious injury or death from electrical shock or fire:

1. DO NOT handle this fixture or try to plug it in when your hands are wet or damp or when you are standing on a wet or damp surface or in water.
2. This fixture must always be used in accordance with all electrical and safety codes and ordinances, including the most recent National Electric Code (NEC) and with the Occupational Safety and Health Act (OSHA) Volume 1 on General Industry Standards and interpretations.
3. Always make certain that the power source conforms to the requirements on the fixture.
4. Always disconnect the power before servicing or inspecting the fixture for any reason.
5. The charging transformer supplied with this unit is only for use on 110-125V circuits.
6. Fixture is not waterproof and is not intended for use in showers, saunas or in potentially wet locations. The entry of moisture into the light may cause damage and void warranty.
7. This light is intended for use as general lighting. DO NOT charge the light in the presents of flammable or explosive gases.
8. Never operate the light with the clear protective lens removed.
9. Never look directly into light source. LEDs are extremely bright and can damage eyes with prolonged exposure.
10. Keep away from heating vents, radiators, or other sources of heat.
11. Do not dispose of dead battery packs in a fire or by burning. NiMH batteries may be disposed of in standard municipal waste system.
12. Keep out of reach of children.

CHARGING INSTRUCTIONS

WARNING: Do not allow anything to cover the light while charging to prevent heat buildup – It is normal for the batteries to become warm during recharge.

Plug transformer into any 110-120 V household electrical outlet. Pull protective cover to expose socket at the base of the light. Plug transformer cord plug into the socket. The red LED on the light will indicate that the light is charging. It will turn green when the light is fully charged. After charging is complete, unplug the cord and remove the transformer from outlet. Always replace the cover after completion of charging to keep dirt and moisture from entering the socket.
NOTE: To obtain best results of the battery life time, recharge the batteries before completely discharged. Batteries cannot be overcharged. Unit is installed with overcharge protection.

LARSON ELECTRONICS LLC • 9419 E US HWY 175 • KEMP, TX 75143
p: 1-800-369-6671 • intl: 903-498-3363 • f: 903-498-3364 • sales@larsonelectronics.com

HANGING WORK LIGHT

Dual Multi-position hanging hooks can be positioned for vertical or horizontal mounting, also rotate 360°. The magnetic clips cling to most metal surfaces.

LAMP REPLACEMENT

DO NOT attempt to replace LED elements. If properly cared for this product will provide up to 50,000 hours of use.

MAINTENANCE

WARNING: Unplug unit before performing any maintenance.

Remove dirt and grime as soon as it accumulates. Use a soft, damp cloth and a mild soap, if needed. Be sure not to get the electrical plug wet. NEVER submerge any part of the work light in any solution to clean it. DO NOT use solvents such as gasoline, turpentine, etc., to clean unit. Dry thoroughly before plugging back into outlet.

LARSON ELECTRONICS LLC • 9419 E US HWY 175 • KEMP, TX 75143
p: 1-800-369-6671 • intl: 903-498-3363 • f: 903-498-3364 • sales@larsonelectronics.com