

HAL-PRM-400-114

Replacement Lens for HAL-PRM Series

WARNING

To avoid the risk of fire, explosion or electric shock, this product should be installed, inspected and maintained by a qualified electrician only, in accordance with all applicable electrical codes.

To avoid electric shock:

- Be certain electrical power is OFF before and during installation and maintenance.

REPLACING LENS

Turn off power supply. Allow the fixture to cool. Remove fixture if necessary.

1. Loosen door frame screws and open frame assembly.
2. Loosen tabs around glass lens.
3. Remove glass lens and leftover sealant.
4. Place new silicone sealant around frame.
5. Place new lens in frame over sealant.
6. Secure lens with tabs loosened in Step 2.
7. Close frame assembly and tighten door frame screws.

CAUTION: *Ensure lens frame is secure before operating!*

MAINTENANCE

CAUTION: To avoid personal injury, disconnect power to the light and allow the unit to cool down before performing maintenance.

Perform visual, mechanical and electrical inspections on a regular basis. We recommend routine checks to be made on a yearly basis. Frequency of use and environment should determine this. It is recommended to follow an Electrical Preventive Maintenance Program as described in NFPA 70B: Recommended practice for Electrical Equipment.

WARRANTY

Should further information not covered by these instructions be required, please contact Larson Electronics at 1-800-369-6671 or sales@larsonelectronics.com for further assistance.

Please visit LarsonElectronics.com for **Warranty** and **Return** information.