

150W Telescoping LED Work Light on Trailer Hitch Mount Instruction Manual

Do not attempt operation until you are familiar with all warnings, precautions, and procedures outlined within this instruction sheet. Read carefully before operating. Retain these instructions for future reference.

WARNING:

- KEEP PLUGS AND RECEPTACLES DRY.
- LAMP RATED IP68 WATERPROOF
- DO NOT TOUCH HOT LENS OR ENCLOSURE.
- DO NOT REMAIN IN LIGHT IF SKIN FEELS WARM.
- DO NOT LOOK DIRECTLY AT LIGHTED LAMP.
- KEEP LAMP AWAY FROM MATERIALS THAT MAY BURN.

USING THE TRIPOD

1. Insert the mounting bracket into your trailer hitch and use trailer pin to secure mount.
2. Place telescoping pole in trailer hitch mount and tighten hand screw until snug.
3. Place LED lamp over the top pole and tighten hand screw.
4. Attach cord to back of light inside deutsch connector.
5. Loosen the black adjustment knob for each adjustment sleeve to extend the tripod. Start with the top section when lifting.
6. Tighten adjustment knob once desired height is achieved.

VEHICLE WIRING

- Connect cord from light to trailer plug **Voltage: 12V or 24V DC** depending on model purchased. **See product label for correct voltage!**

LED OPERATION

This light is "instant-on" and will illuminate once power is supplied. Do not look directly at LED's when turning on.

WARNING: DO NOT DRIVE WITH LIGHT TOWER DEPLOYED!

USE AND CARE

Always check damaged or worn out parts before using the work light. Broken parts will affect operation. When not in use, store work light in a secure place out of the reach of children. The light tower can be completely disassembled for storage. Inspect it for good working condition prior to storage and before re-use.

MAINTENANCE

Maintain your work light. It is recommended that the general condition of any work light be examined before it is used. Keep your work light in good repair by adopting a program of conscientious repair and maintenance. Have necessary repairs made by qualified service personnel.

Should further information not covered by these instructions be required, please contact Larson Electronics at 1-800-369-6671 or sales@larsonelectronics.com for further assistance.

Please visit LarsonElectronics.com for **Warranty** and **Return** information.

