

LED Tactical Flashlight INSTRUCTION MANUAL

Thank you for your purchase of the Larson Electronics MK-1 LED Tactical Flashlight. Do not attempt operation until you are familiar with all warnings, precautions, and procedures outlined within this instruction sheet. Read carefully before operating. Retain these instructions for future reference.

WARNING:

WARNING: USE OF LIGHT IN "STROBE" MODE MAY CAUSE SEIZURE IN PERSONS WITH PHOTOSENSITIVE EPILEPSY.

CAUTION: THE MK-1 PROVIDES A POWERFUL BEAM. WHEN OPERATED FOR A LONG TIME, IT WILL GET UNCOMFORTABLY WARM. THIS IS NORMAL AND IS NOT A DEFECT. ANY LED FLASHLIGHT OF SIMILAR SIZE AND PERFORMANCE WILL PRODUCE SIMILAR AMOUNTS OF HEAT DURING OPERATION. THE ONLY WAY TO REDUCE OPERATING HEAT IS TO SIGNIFICANTLY LOWER THE OUTPUT, OR INCREASE THE SIZE OF THE FLASHLIGHT. WHILE THIS HEATING MAY TRIGGER THE DROP REFLEX IF AN UNATTENDED HOT LIGHT IS PICKED UP, THE TEMPERATURE DOES NOT PRESENT A BURN HAZARD. WHEN USED TACTICALLY FOR SHORT PERIODS OF TIME TO CLEAR A ROOM, CHECK FOR INTRUDERS, ETC., HEATING WILL NOT BE A PROBLEM.

WARNING:

THE MK-1 UTILIZES A HIGH LUMEN LED THAT CAN GET VERY HOT. NEVER PLACE THE MK-1 FACE-DOWN AGAINST A FLAT SURFACE OR AGAINST ANY FLAMMABLE OBJECT. TRANSPORT OR STORE THE MK-1 IN A WAY THAT MINIMIZES THE CHANCE IT CAN ACCIDENTALLY BE TURNED ON.

NOTE: THIS PRODUCT IS NOT DESIGNED TO USE RECHARGEABLE CR123 CELLS.

BATTERY INSTALLATION/REMOVAL

Remove the tail cap. Place the two CR123 batteries into the tube, positive end first and replace the tail cap. For removal, remove the tail cap and dump the cells into your hand.

The light will also function if you install a commercially available "Li Ion 18650 protected cylindrical 3.7V 2600mAh 'button top' rechargeable battery" that have their own charging cradle system.

GENERAL OPERATION

The MK-1 features a programmable switch with momentary operation (light press or tap) and constant on operation (press until click). The light is shipped from the factory in the default High-Strobe-Low program.

- **High:** Tap and hold; click to lock on; click again for off.
- **Strobe:** Fast double-tap (within 0.4 seconds) and hold; click to lock on; click again for off.
- **Low:** Fast triple-tap (within 0.4 seconds per tap) and hold; click to lock on; click again for off.

Accessing Other Programs

The MK-1 features a programmable switch allowing the user to select one of three different programs. To change to the next program, starting from the "Off" position, tap the switch rapidly 9 times (within 0.4 seconds per tap) and hold it down the 10th time. Continue holding the switch until the light turns off (approximately 1 second), then release the switch.

Available programs are **High-Strobe-Low** (Factory Default), **High Only** or **Low-Medium-High**.

MAINTENANCE AND SERVICE

It is important to keep the O-ring on the tail cap lubricated. Larson Electronics recommends the factory or authorized service centers for any repairs.

SHOULD FURTHER INFORMATION NOT COVERED BY THESE INSTRUCTIONS BE REQUIRED, PLEASE CONTACT LARSON ELECTRONICS BY EMAIL AT SALES@LARSONELECTRONICS.COM OR BY PHONE AT 1-800-369-6671 FOR FURTHER ASSISTANCE.

PLEASE VISIT LARSONELECTRONICS.COM FOR **WARRANTY** AND **RETURN** INFORMATION.