

High Output 150 Watt High Bay LED Light Fixture Instruction Manual

This High Bay LED fixture is designed for illumination of industrial locations. It uses the latest in solid state lighting technology for long life, low maintenance and high efficiency.

The unique design focuses the light where it is needed, giving improved efficiency over a conventional HID luminaire.

This light fixture is shipped preconfigured to work in the selected voltage range. This includes 120-277V AC 50/60hz or 12-24V AC/DC depending on model selected. An internal, universal input power-factor-corrected switch allows it to be used from any voltage within range without variation in light output. *Check product label for correct input voltage!*

WARNING

To avoid the risk of fire, or electric shock, this product should be installed, inspected and maintained by a qualified electrician only, in accordance with all applicable electrical codes.

To avoid electric shock:

- Be certain electrical power is OFF before and during installation and maintenance.
- Luminaire must be connected to a wiring system with an equipment-grounding conductor.

This light is designed for illumination of general area locations that do not require explosion proof protection.


For supply connections, use wire rated for at least 110°C
Recommended mounting height is 25-40 feet.

MOUNTING

This fixture offers an adjustable mounting system that allows it to be mounted to any flat surface including walls and ceilings. A single ½-13 bolt is used to mount the fixture to the surface.

Check to ensure that all mounting hardware is included.

- 2 Small Brackets
 - 1 Large Trunnion Bracket
 - 8 Bolts
 - 8 Lock-Washers
 - 4 Nuts
1. Using four bolts, washers and the four nuts provided, attach brackets "A" to both sides of bracket "B".
 2. The LED fixture has 9 holes for a versatile mount option. Select the holes that you would like to use.
 3. Brackets "A" will then be bolted to the LED fixture with the remaining bolts and washers.
 4. The fixture is now ready for installation.



Trunion Bracket

WIRING (see attached wiring diagram)

This unit comes preconfigured in the selected voltage, beam angle, and color temperature. Wire light to the correct voltage. Follow all applicable local, state, and National Electrical Code for the hazardous area!



WARNING: CHECK NAMEPLATE FOR PROPER VOLTAGE. DAMAGE FROM IMPROPER VOLTAGE WILL VOID WARRANTY.

MAINTENANCE

Caution: To avoid personal injury, disconnect power to the light and allow the unit to cool down before performing maintenance.

Warning: No user serviceable parts inside of fixture. Risk of electric shock. Removal of the lens will void the warranty.

1. Perform visual, mechanical and electrical inspections on a regular basis. We recommend routine checks to be made on a yearly basis. Frequency of use and environment should determine this. It is recommended to follow an Electrical Preventive Maintenance Program as described in NFPA 70B: Recommended practice for Electrical Equipment.
2. The lens should be cleaned periodically as needed to ensure continued photometric performance. Clean the lens with a damp, non-abrasive, lint-free cloth. If not sufficient, use mild soap or a liquid cleaner.
3. Inspect the cooling fins on the luminaire to ensure that they are free of any obstructions or contamination (i.e. excessive dust build-up). Clean with a non-abrasive cloth if needed.
4. Do not operate if the lens is cracked or damaged. All fasteners should be properly seated.

Should further information not covered by these instructions be required, please contact Larson Electronics at 1-800-369-6671 or sales@larsonelectronics.com for further assistance.

Please visit LarsonElectronics.com for **Warranty** and **Return** information.