

LE-2317C

Explosion Proof Flashlight Instruction Manual



E X P E D I T E D S H I P P I N G · S U P E R I O R C U S T O M F A B R I C A T I O N

LARSON ELECTRONICS LLC · 9419 E US HWY 175 · KEMP, TX 75143

p: 1-800-369-6671 · intl: 903-498-3363 · f: 903-498-3364 · sales@larsonelectronics.com



Congratulations on the purchase of your new Handheld Waterproof and Explosion Proof Flashlight. Please read these instructions carefully to familiarize yourself with the safe operation and maintenance of your new flashlight. Following these instructions will insure many years of safe and dependable service.

Table of Contents

I. Operating Instructions	2
I.I Assembly	2
I.II Operation	2
II. Bulb Replacement	3
III. Warnings	4
VI. Warranty and Disclaimer	5
VI.I Limitation of Liability	5
VI.II Conditions	5
VII. Return Requests and Inquiries	6
8.1 Warranty Returns	6
8.2 Non-Warranty Returns	6

I. Assembly and Operation

I. Assembly

Unscrew the bottom cap and install approved batteries like shown below. Once batteries have been placed, screw the bottom cap back on.

II. Operation

This flashlight features a simple slide switch for easy operation. Operators slide the switch up to turn on, down to turn off or in the middle for momentary.



II. Bulb Replacement

I. Replacement

Begin by unscrewing the lens cap of the flashlight. The light housing is held together with the lens cap by clicking into place. To separate the the housing and the lens cap simply apply force and pull them apart.

(Note: The bulb is held in place via a spring attached to the lens, upon separation of the housing and lens cap the bulb will be free, be careful not to drop, lose, or break the bulb.)

The bulb is now free to be replaced.





III. Safety Warnings and Ratings

For personal safety, always follow the safety instructions in this manual to ensure safe and long-term use. Failing to do so can result in damage to the product or serious bodily injury.

I. Safety Warnings

Never place flashlight face down when light is on or is still hot from recent use. Doing so could burn/ignite surfaces such as seats, carpeting, etc. and cause major property damage. Always turn spotlight off when not in use.

To prevent serious damage to eyesight, never look into the flashlight when light is on. **DO NOT** shine light into the face of someone else.

DO NOT touch the lens of the flashlight when light is on or if it was recently on. The lens will be hot and could cause serious burns.

DO NOT allow children to handle or operate this flashlight.

DO NOT use this product for other than its intended use.

DO NOT operate in close proximity of combustible or flammable materials.

DO NOT attempt to operate this spotlight if cord, plug, battery, bulb or any part of the spotlight is damaged or corroded.

DO NOT remove lens ring.

DO NOT allow metal parts to touch metal contacts on battery as this can cause a short circuit and result in a fire.

II. Ratings

Class I, Division 1, Group C & D

Class I, Division 2, Group A, B, C, & D

Class II, Division 2, Group G - Class 3

CSA: Class I, Division 1, Group C & D

CSA: Class II, Division 1, Group G - Temp T3C

ASTM & MSHA: Approved



IV. Warranty and Disclaimer

Larson Electronics', LLC. LarsonElectronics.com warrants this unit to be free of defects in materials and workmanship for a period of three (3) years from the date of purchase.

If the unit should malfunction, it must be returned to the factory for evaluation. Larson Electronics' Customer Service Department will issue a Returned Merchandise Authorization (RMA) number immediately upon phone or written request. Upon examination by Larson Electronics', if the unit is found to be defective it will be repaired or replaced at no charge. Larson Electronics' WARRANTY does not apply to defects resulting from any action of the purchaser, including but not limited to mishandling, improper interfacing, operation outside of design limits, improper repair, or unauthorized modification. This WARRANTY is VOID if the unit shows evidence of having been tampered with or shows evidence of being damaged as a result of excessive corrosion; or current, heat, moisture or vibration; improper specification; misapplication; misuse or other operating conditions outside of Larson Electronics' control.

Larson Electronics' is pleased to offer suggestions on the use of its various products. However, Larson Electronics' neither assumes responsibility for any omissions or errors nor assumes liability for any damages that result from the use of its products in accordance with information provided by Larson Electronics', either verbal or written. Larson Electronics' warrants only that the parts manufactured by it will be as specified and free of defects.

LIMITATION OF LIABILITY

The remedies of purchaser set forth herein are exclusive and the total liability of Larson Electronics' with respect to this order, whether based on contract, warranty, negligence, indemnification, strict liability or otherwise, shall not exceed the purchase price of the component upon which liability is based. In no event shall Larson Electronics' be liable for consequential, incidental or special

CONDITIONS

Should any Product(s) be misused in any way, Larson Electronics' assumes no responsibility as set forth in our basic WARRANTY / DISCLAIMER language, and additionally purchaser will indemnify Larson Electronics' and hold Larson Electronics' harmless from any liability or damage whatsoever arising out of the use of the Product(s) in such a manner.



V. Return Requests and Inquiries

Direct all warranty and repair requests/inquiries to the Larson Electronics' Customer Service Department. **BEFORE RETURNING ANY PRODUCT(S) TO LARSON ELECTRONICS', PURCHASER MUST OBTAIN A RETURNED MERCHANDISE AUTHORIZATION (RMA) NUMBER FROM LARSON ELECTRONICS' CUSTOMER SERVICE DEPARTMENT (IN ORDER TO AVOID PROCESSING DELAYS).** The assigned RMA number should then be marked on the outside of the return package and on any correspondence.

The purchaser is responsible for shipping charges, freight, insurance and proper packaging to prevent breakage in transit.

For **WARRANTY RETURNS** please have the following information available **BEFORE** contacting Larson Electronics

III.I Order number under which the product was PURCHASED.

III.II Model and serial number of the product under warranty.

3. Repair instruction and/or specific problems relative to the product.

For **NON-WARRANTY REPAIRS** consult Larson Electronics LLC for current repair charges. Have the following information available **BEFORE** contacting Larson Electronics LLC:

1. Order number to cover the **COST** of the repair.

2. Model and serial number of product.

3. Repair instructions and/or specific problems relative to the product.

Larson Electronics' policy is to make running changes, not model changes, whenever an improvement is possible. This affords our customers the latest in technology and engineering.

Larson Electronics' is a registered trademark of LARSON ELECTRONICS', LLC. © Copyright 2017 LARSON ELECTRONICS LLC. All rights reserved. This document may not be copied, photocopied, reproduced, translated, or reduced to any electronic medium or machine-readable form, in whole or in part, without prior written consent of LARSON ELECTRONICS' LLC.