

Replacement Surface Mount Bracket for TPM Pole Mount Lights Instruction Manual

Do not attempt operation until you are familiar with all warnings, precautions, and procedures outlined within this instruction sheet. Read carefully before operating. Retain these instructions for future reference.

WARNING:

- INSTALL AWAY FROM ANY ELECTRICAL WIRES OR OVERHEAD POWER LINES.
- DO NOT OVERLOAD TELESOPING POLE.


Replacement Surface Mount Bracket for TPM Pole Mount Lights

INSTALLATION

1. Utilize the predrilled holes and mount the bracket in a location that can support the load. Utilize screws/bolts that can accommodate the load and environment.
2. Place telescoping pole in mount and tighten hand screw until snug.
3. Loosen hand screw to remove pole from mount.

USE AND CARE

Always check damaged or worn out parts before use. Broken parts will affect operation. When not in use, store in a secure place out of the reach of children. Inspect it for good working condition prior to storage and before re-use.



THESE INSTRUCTIONS MAY NOT COVER ALL DETAILS OR VARIATIONS OF THIS PRODUCT FOR YOUR EQUIPMENT OR INSTALLATION REQUIREMENTS. SHOULD FURTHER INFORMATION NOT COVERED BY THESE INSTRUCTIONS BE REQUIRED, PLEASE CONTACT LARSON ELECTRONICS BY EMAIL AT SALES@LARSONELECTRONICS.COM OR BY PHONE AT 1-800-369-6671 FOR FURTHER ASSISTANCE.

PLEASE VISIT LARSONELECTRONICS.COM FOR **WARRANTY** AND **RETURN** INFORMATION.