

CHASSIS GROUND
14 GAUGE WIRE
BATTERY
20 AMP FUSE
CHASSIS GROUND
RELAY
87
86
30
85
14 GAUGE
SWITCH
14 GAUGE WIRE
20 AMP FUSE
14 GAUGE
ADD AN ADDITIONAL 12 GAUGE CHASSIS GROUND FOR EACH RELAY